

# TRM240 Powering Options

[Main Page](#) > [TRM Modems](#) > [TRM240](#) > [TRM240 Manual](#) > **TRM240 Powering Options**

This chapter contains information on **powering options** supported by TRM240 routers.



## Contents

- [1 USB connector](#)

## USB connector

This device has a USB connector and is powered via a micro USB cable. Operating Voltage - 5V.

