https://wiki.teltonika-networks.com/view/TSW010_LEDs

TSW010 LEDs

```
<u>Main Page</u> > <u>TSW Switches</u> > <u>TSW010</u> > <u>TSW010 Manual</u> > TSW010 LEDs
```

This wiki page contains information about TSW010 switch LEDs and their actions.

Contents

- <u>1 Power LED</u>
- <u>2 Ethernet port</u>

Power LED

The **power LED** is located on the bottom left corner of the front panel, near the power connector:

×

It can perform two different actions:

Action

LED turned ON LED turned OFF Switch is powered up Switch is not power up Description

Ethernet port

There is one **LEDs** located at the top-left of each **Ethernet port** (top-right green port is unused).

×

They provide information on the current states of the Ethernet ports. Each port has one LED:

Orange - 10/100 Mbps connection

Below is an explanation on the behaviours of orange LEDs.

	State	Description
LED on		A data connection on the port is operational (cable plugged in, end device visible, no data is being transferred).
LED off		No data connection on the port is operational (no cable, bad cable or end device not visible for some other reason (such as damaged network card)).
LED blinking		Connection established and data is being transferred over this port.