https://wiki.teltonika-networks.com/view/TSW304_LEDs

TSW304 LEDs

<u>Main Page</u> > <u>TSW Switches</u> > <u>TSW304</u> > <u>TSW304 Manual</u> > **TSW304 LEDs**

This wiki page contains information about TSW304 switch LEDs and their actions.

Contents

- <u>1 Power LED</u>
- <u>2 Ethernet port</u>

Power LED

The **power LED** is located on the bottom left corner of the front panel, near the power connector:

×

It can perform two different actions:

	Action		Description
LED turned ON		Switch is powered up	
LED turned OFF		Switch is not power up	

Ethernet port

No.	Action	Describtion	
1	<mark>Orange</mark> LED lit	10/100 Mbps link established	
1	Orange LED blinking	Active link connection	×
2	Green LED lit	1000 Mbps link established	