

# Template:Networking rut230 manual modbus modbus tcp set parameters table

| value to set                            | register address | register value | description                                                                                                                                                               |
|-----------------------------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hostname                                | 7                | Hostname       | Changes hostname                                                                                                                                                          |
| Device name                             | 71               | Device name    | Changes device name                                                                                                                                                       |
| Switch WiFi (ON/OFF*)                   | 203              | 1   0          | Turns WiFi ON or OFF                                                                                                                                                      |
| Switch mobile data connection (ON/OFF*) | 204              | 1   0          | Turns mobile data connection ON or OFF                                                                                                                                    |
| Reboot                                  | 206              | 1              | Reboots the router                                                                                                                                                        |
| Change APN                              | 207              | APN code       | Changes APN.<br>The number of input registers may vary depending on the length of the APN, but the very first byte of the set APN command has to be specified as <b>1</b> |
| Switch PIN4 state (ON/OFF*)             | 325              | 1   0          | Turns PIN4 state ON or OFF                                                                                                                                                |