

https://wiki.teltonika-networks.com/view/Template:Networking_rutx_manual_input_output_input_input_rules_modem

Template:Networking rutx manual input output input input rules modem

1. **Send SMS** - sends an SMS message with user specified text to the specified recipient(s).