

Template:Rms manual management configuration my alerts

The **Device alerts** purpose is manage alerts that were created for the selected device in the RMS. To manage alert(s) go to Left sidebar panel (**Management** → **Devices**) and click on **Devices** submenu.

Move your mouse pointer to the Top control **Alerts** menu and select **Device alerts** (Devices → Device alerts).




The **Device alerts** function is used to view and delete already existing alerts on a device.

Instructions

1. Select the device for which you want to manage alert(s).
2. Move your mouse pointer to the top control **Alerts** menu and select **Device alerts**.
3. A pop-up window listing alerts for the selected device will appear.

Delete device alert

1. Select the device for which you want to manage alert(s).
2. Move your mouse pointer to the top control **Alerts** menu and select **Device alerts**.
3. A pop-up window will be shown a list of alerts existing in the selected device.
4. You can delete alerts by clicking the  symbol located next to each alert.
5. In the next window you will get a **Remove device alert** confirmation message. Click **Yes** to proceed.
6. After the deletion is complete in the Status column you will get a message: **Alert removed successfully**.

