



Template:Rms manual reports delete

The **Remove** function is used to remove the report template from RMS. It works in the same for single reports and periodic reports.



Instruction

1. Go to the report row that you would like to remove.
2. To remove the report template click on  **Remove** button.

At the top of your screen, you will get a notification in green text:  **Report deleted.**

