

Template:Rut230 connection status leds table

The LED displays the router's current connection state and network type among a few other things:

ACTION	DESCRIPTION
2G and 3G LEDs blinking every 1 second	No SIM or bad PIN
Blinking from 2G LED to 3G LED repeatedly	SIM holder is not inserted or access to network is denied
2G/3G LED blinking every 1 sec	Connected to 2G/3G, no data session established
2G/3G LED turned on	Connected to 2G/3G with data session
2G/3G LED blinking rapidly	Connected to 2G/3G with data session and data is being transferred