

Template:Rut850 connection status leds table

The LEDs display the router's current connection state and network type among a few other things:

ACTION	DESCRIPTION
2G, 3G and 4G LEDs blinking every 1 sec	No SIM or bad PIN
Repeated blinking from 2G LED to 4G LED	SIM holder not inserted
2G LED blinking every 1 sec	Connected 2G, no data session established
3G LED blinking every 1 sec	Connected 3G, no data session established
4G LED blinking every 1 sec	Connected 4G, no data session established
2G LED turned ON	Connected 2G with data session
3G LED turned ON	Connected 3G with data session
4G LED turned ON	Connected 4G with data session
2G LED blinking rapidly	Connected 2G with data session and data is being transferred
3G LED blinking rapidly	Connected 3G with data session and data is being transferred
4G LED blinking rapidly	Connected 4G with data session and data is being transferred