

Template:Webui services rs232 rs232 configuration modbus gateway

The **Modbus gateway** serial type allows redirecting TCP data coming to a specified port to the RTU specified by the Slave ID. The Slave ID can be specified by the user or be obtained directly from the Modbus header.

The figure below is an example of available configuration fields for the Modbus gateway serial type and the table below provides information on these fields: