Template:Networking trm manual powering options power socket

This device has a USB connector and is powered via a micro USB cable. Operating Voltage - 5V.