

TRB245 Package Manager

[Main Page](#) > [TRB Gateways](#) > [TRB245](#) > [TRB245 Manual](#) > [TRB245 WebUI](#) > [TRB245 System section](#) > **TRB245 Package Manager**

The information in this page is updated in accordance with firmware version [TRB2_R_00.07.07.3](#).



Contents

- [1 Summary](#)
- [2 Packages](#)
 - [2.1 Package Restore](#)
 - [2.2 Package Manager](#)
- [3 Upload](#)
- [4 Verification](#)
- [5 FAQ](#)

Summary

The **Package Manager** is a service used to install additional software on the the device. This page is an overview of the Package Manager section in TRB245 devices.

If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.



Packages

Package Restore

The **Package Restore** section `Enable` or `Disable` automatic package installation function after firmware upgrade with keep settings.



Package Manager

The **Package Manager** section provides the possibility to install additional software packages that

are available for download from the FOTA server. To install a new service, locate the necessary package in the list, click the '+' button adjacent to it.

Note: Package Manager in your device might show different available packages, the picture below is just for demonstration:



Upload

The **Upload** section provides the possibility for offline package installation. Only packages that are intended for this specific device and firmware version can be uploaded.

The list of available packages for TRB245 devices with latest firmware version can be found in the [Package Downloads](#) page. Also it can be found by clicking on **this repository** link.



To install a package click the 'Browse' button and locate the package file on your computer. Package should start uploading and a [Verification](#) windows should soon appear. If you proceed with installation and successfully install the package, you should see a pop-up containing a message of success in the top side of your screen:



Verification

When trying to install a package by uploading it in [Upload](#) page you will be informed whether this package is **Authorized** - digitally signed by Teltonika Networks, or **Unauthorized** - without digital signature. After that you will be able to proceed with installation or cancel it.

Below are pictures representing **Authorized** and **Unauthorized** packages respectively.



FAQ

- **Q:** How to keep installed packages after firmware upgrade?
- **A:** Before upgrading the device's firmware, make sure the 'Keep settings' option is checked in the [Firmware](#) page and 'Package Restore' function is enabled in the [Package Manager](#). This ensures that the device will install the necessary packages after FW upgrade and keep user configuration data.



-
- **Q:** Is there enough space for packages that I want to install?
 - **A:** The size of each package is displayed next to its version in the package list. The current state of Flash memory is displayed in in the top-right corner of the list. Hover your mouse over

it for more information.



-
- **Q:** I installed a software package, how do I configure it?
 - **A:** After the installation of a package, a related configuration page is generated somewhere in the WebUI, depending on the packages purpose. You can find a redirect to the configuration page by locating your package in the [Services](#).

-
- **Q:** The package that I want isn't on the list. Can I install it anyway?
 - **A:** Depends on what you need specifically. More packages can be downloaded using the **opkg package manager**. It is a [command-line](#) utility used to download software from special online repositories.

Before using *opkg* you should first update the list of available packages by executing this command:

```
opkg update
```

To see a list of available packages, use this command:

```
opkg list
```

To install a package, use this syntax:

```
opkg install <PACKAGE_NAME>
```