

# RUT950 Monitoring via JSON-RPC linux

[Main Page](#) > [RUT Routers](#) > [RUT950](#) > [RUT950 Configuration Examples](#) > **RUT950 Monitoring via JSON-RPC linux**

□

## Contents

- [1 Introduction](#)
- [2 Configuration overview and prerequisites](#)
- [3 Enabling JSON-RPC](#)
- [4 Using JSON-RPC \(Linux\)](#)
  - [4.1 Obtaining a session ID](#)
  - [4.2 Getting router parameters](#)
    - [4.2.1 Getting RSSI](#)
  - [4.3 Setting router parameters](#)
    - [4.3.1 UCI SET](#)
    - [4.3.2 UCI COMMIT](#)
    - [4.3.3 LUCI-RELOAD](#)
    - [4.3.4 Setting Multiple Parameters](#)
- [5 Some Additional Commands](#)
  - [5.1 WiFi clients list](#)
  - [5.2 WiFi information](#)
  - [5.3 Manufacturing information](#)
  - [5.4 GPS Data](#)
  - [5.5 Firmware number](#)
  - [5.6 Reboot](#)
  - [5.7 Set SIM card information](#)

## Introduction

The information in this page is updated in accordance with the [RUT9XX\\_R\\_00.06.06.1](#) firmware version.

**JSON-RPC** is a remote procedure call protocol encoded in JSON. It is a very simple protocol (and very similar to XML-RPC), defining only a few data types and commands. JSON-RPC allows for notifications (data sent to the server that does not require a response) and for multiple calls to be sent to the server which may be answered out of order.

This article provides a guide on how to use JSON-RPC on RUTxxx routers.

## Configuration overview and prerequisites

Before we begin, let's overview the configuration that we are attempting to achieve and the prerequisites that make it possible.

### Prerequisites:

- A PC for with a HTTP request software.



## Getting RSSI

---

This is a command that returns the router's **RSSI**(signal strength) value:

```
curl -d "{ \"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\": [\"a74c8e07646f0da2bfdce35bf3de1f3\", \"file\", \"exec\", { \"command\": \"gsmctl\", \"params\": [\"-q\"] } ] }" http://192.168.1.1/ubus
```

Highlighted in red is the Session ID. Replace it with the Session ID that was provided to you.

Highlighted in orange is the command that we used for our query and highlighted in green is the parameter for the command: **gsmctl -q**.

The picture bellow is a visual representation of this example. Encapsulated in a blue rectangle is the answer to the *gsmctl -q* query: **-73 dBm**.



You can issue almost any Linux command in a similar manner. For example, if you wish to get a list of file names contained in the config folder, the Linux command to do so would be **ls /etc/config**, which, translated to JSON-RPC, would be:

```
curl -d "{ \"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\": [\"a74c8e07646f0da2bfdce35bf3de1f3\", \"file\", \"exec\", { \"command\": \"ls\", \"params\": [\"/etc/config\"] } ] }" http://192.168.1.1/ubus
```



The command is encapsulated in an orange rectangle and the answer - in a blue one.

## Setting router parameters

---

This section will describe how to use **uci set** commands in order to set or change various router parameters via JSON-RPC. For more general information about the usage and syntax of UCI commands, check out our [UCI command usage](#) guide.

### UCI SET

---

The *uci set* command is used to set router parameters. As an example, lets try to change the router's **LAN IP address**. The command to do so looks like this:

```
curl -d "{ \"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\": [\"590bde71578da2fabfe77ba86c00e4e5\", \"uci\", \"set\", { \"config\": \"network\", \"type\": \"interface\", \"match\": { \"ipaddr\": \"192.168.1.1\" }, \"values\": { \"ipaddr\": \"192.168.56.1\" } } ] }" http://192.168.1.1/ubus
```

The sections highlighted in orange describe the config file's name and section (in this case, network config and interface section). Highlighted in red is the option in the config file that you wish to change (in this case, the router's LAN IP address, **ipaddr**). Finally, highlighted in green is the value that will replace the old value (in this case, change the router's LAN IP address to 192.168.56.1). If the command was issued successfully, you should see a Response like this:



## UCI COMMIT

---

In order to commit the changes from RAM to flash memory, you must execute a **uci commit** command. Continuing from the example above, let's commit the changes made to the *network* config. The command to do so looks like this:

```
curl -d "{\"jsonrpc\":\"2.0\", \"id\":1, \"method\":\"call\",  
\"params\": [\"9704f676709d9dedc98d7718c4e3e7d2\", \"uci\", \"commit\",  
{\"config\":\"network\"} ] }" http://192.168.1.1/ubus
```

When committing changes, you will need to specify the name of the file where the changes took place (in this case, network, which is highlighted in orange). If the commit was successful, you should see the same message as before:

```
{\"jsonrpc\":\"2.0\", \"id\":1, \"result\":[0]}
```

## LUCI-RELOAD

---

In order for the changes to take effect, use the **luci-reload** command which restarts all of the router's services. The luci-reload command looks like this:

```
curl -d "{\"jsonrpc\":\"2.0\", \"id\":1, \"method\":\"call\",  
\"params\": [\"428a9fa57f1a391db0bd1b865fa16bb5\", \"file\", \"exec\",  
{\"command\": \"luci-reload\"} ] }" http://192.168.56.1/ubus
```

The command itself is highlighted in orange.

## Setting Multiple Parameters

---

This next example describes how to set multiple parameters in a single config file with one command. Let's change the default configuration of the Ping Reboot function (ping\_reboot config file):

```
curl -d "{\"jsonrpc\":\"2.0\", \"id\":1, \"method\":\"call\",  
\"params\": [\"558a9b03c940e52f373f8c02498952e3\", \"uci\", \"set\",  
{\"config\":\"ping_reboot\", \"match\":{\"enable\":\"0\"},  
\"host\":\"8.8.8.8\", \"packet_size\":\"56\"}, \"values\":{\"enable\":\"1\",  
\"host\":\"8.8.4.4\", \"packet_size\":\"64\"} } ] }" http://192.168.1.1/ubus
```

The command above will **enable** the Ping Reboot function, set the host to ping to **8.8.4.4** and ping packet size to **64**. The default values are highlighted in orange and the new ones are highlighted in green.

**Note: Remember always to use the commands in the order (set, commit, luci-reload)**

## Some Additional Commands

If the commands found in the guide above did not suffice your needs, this section provides a list of additional ones. The commands presented in this section will be for both Linux and Windows operating systems. They should be used as syntax examples for your own purposes.

### WiFi clients list

---

This command returns a list of devices connected to your WLAN and some additional information about the connection.

#### Windows:

```
{
  "jsonrpc": "2.0", "id": 1, "method": "call", "params":
  [
    "86fc586fa1471622473434ff0176fd66", "iwinfo", "assoclist",
    {
      "device": "wlan0"
    }
  ]
}
```

#### Linux:

```
curl -d "{ \"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\":
[ \"86fc586fa1471622473434ff0176fd66\", \"iwinfo\", \"assoclist\",
{\"device\": \"wlan0\"} ] }" http://192.168.1.1/ubus
```

**The response** should look something like this:

```
{"jsonrpc": "2.0", "id": 1, "result": [0, {"results":
[{"mac": "E4:02:9B:88:09:AA", "signal": -32, "noise": -88, "inactive": 10, "rx":
{"rate": 1000, "mcs": 0, "40mhz": false, "short_gi": false}, "tx":
{"rate": 72200, "mcs": 7, "40mhz": false, "short_gi": true}},
{"mac": "D8:C7:71:47:90:E1", "signal": -12, "noise": -88, "inactive": 400, "rx":
{"rate": 1000, "mcs": 0, "40mhz": false, "short_gi": false}, "tx":
{"rate": 72200, "mcs": 7, "40mhz": false, "short_gi": true}}]}]}
```

To obtain these values, the Linux **iwinfo** command and **assoclist** parameter (red) are used. Highlighted in green are the devices connected to the router via WiFi as identified by their MAC addresses. The response information about the connection with the device, such as signal strength, noise, time of inactivity (idle time), rx, tx rate, etc., is highlighted in blue.

## WiFi information

---

This command returns information on your WiFi Access Point.

### Windows:

```
{
  "jsonrpc": "2.0", "id": 1, "method": "call", "params":
  [
    "a70ceebeba344b6046625d8bcec132796c", "iwinfo", "info",
    {
      "device": "wlan0"
    }
  ]
}
```

### Linux:

```
curl -d "{ \"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\":
[ \"a70ceebeba344b6046625d8bcec132796c\", \"iwinfo\", \"info\",
{\"device\": \"wlan0\"} ] }" http://192.168.1.1/ubus
```

### Response:

```
{"jsonrpc": "2.0", "id": 1, "result": [0,
{"phy": "phy0", "ssid": "HAL9000", "bssid": "00:1E:42:16:D6:68", "country": "00", "mode": "Master", "channel": 6, "frequency": 2437, "txpower": 20, "quality": 22, "quality_max": 70, "signal": 22, "noise": -61, "bitrate": 72200, "encryption": {"enabled": false}, "hwmodes": ["b", "g", "n"], "hardware": {"name": "Generic MAC80211"}}]}
```

As with the clients list command described above, to obtain this information the Linux **iwinfo** command is used, but this time with the **info** parameter (red). The relevant information, such as WiFi SSID, WiFi MAC address, WiFi channel, Encryption type, etc., is highlighted in blue

## Manufacturing information

---

This command returns information about the device's manufacturing details like device's Product Code, Serial Number MAC Address, etc.

### Windows:

```
{
  "jsonrpc": "2.0", "id": 1, "method": "call", "params":
```

```
[
  "805725a19ab0fba6c2b44ecf2f952fb9", "file", "exec",
  {
    "command": "mnf_info", "params": ["name", "sn", "mac"]
  }
]
```

### Linux:

```
curl -d "{ \"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\": [ \"805725a19ab0fba6c2b44ecf2f952fb9\", \"file\", \"exec\", { \"command\": \"mnf_info\", \"params\": [\"name\", \"sn\", \"mac\"] } ] }"
http://192.168.1.1/ubus
```

### Response:

```
{"jsonrpc": "2.0", "id": 1, "result": [0, {"code": 0, "stdout": "RUT950HG12C0\n1367435694\n001e4216d666\n"}]}
```

To obtain the manufacturing information the **mnf\_info** (highlighted in red) command is used. In this case a query was sent asking for the device's Product Code (name), Serial Number (sn) and MAC Address (mac) (highlighted in red in the query; returned values highlighted in blue). Using *mnf\_info*, you can "ask" the router for any type of manufacturing information. Here is the list of possible *mnf\_info* parameters:

- **mac** - returns the router's LAN MAC address
- **maceth** - returns the router's WAN MAC address
- **name** - returns the router's Product Code
- **wps** - returns the router's WPS PIN number
- **sn** - returns the router's Serial number
- **batch** - returns the router's Batch number
- **hwver** - returns the router's Hardware Revision number
- **simpin** - returns the router's SIM card's PIN (as it is specified in the [RUT950\\_Mobile](#) section)
- **blver** - returns the router's Bootloader version

## GPS Data

---

This command returns the device's GPS latitude and longitude.

### Windows:

```
{
  "jsonrpc": "2.0", "id": 1, "method": "call", "params": [
    "456f77f6b686bf5972daa3a26bee60b0", "file", "exec",
    {
```

```
        "command": "gpsctl", "params": ["-ix"]
    }
]
}
```

### Linux:

```
curl -d
"{\"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\": [\"5363304b3ed4
ee0806f101295fc52e93\", \"file\", \"exec\", {\"command\": \"gpsctl\", \"params\": [
\"-ix\"]}]}" http://192.168.1.1/ubus
```

Response:

```
{"jsonrpc": "2.0", "id": 1, "result": [0, {"code": 0, "stdout": "-23.612625\n-46.62635
5\n"}]}
```

The blue part in the code are the Latitude and Longitude.

## Firmware number

---

This command returns the device's Firmware version number.

### Windows:

```
{
  "jsonrpc": "2.0", "id": 1, "method": "call", "params":
  [
    "85ea4cb00398d8387b22d8fa6f75f753", "file", "read",
    {
      "path": "/etc/version"
    }
  ]
}
```

### Linux:

```
curl -d "{ \"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\":
[ \"85ea4cb00398d8387b22d8fa6f75f753\", \"file\", \"read\", {
\"path\": \"\"/etc/version\"\" } ] }" http://192.168.1.1/ubus
```

### Response:

```
{"jsonrpc": "2.0", "id": 1, "result": [0, {"data": "RUT9XX_R_00.05.00.5\n"}]}
```

This command (**file read**, highlighted in red) is an alternative to the Linux **cat** command. All you need is to specify the path (in this case **/etc/version**, highlighted in red) to the file that you wish to read.



## Reboot

---

### Windows:

```
{
  "jsonrpc": "2.0", "id": 1, "method": "call", "params":
  [
    "5cd4b143b182c07bc578ae3310d6280e", "file", "exec",
    {
      "command": "reboot", "params": ["config"]
    }
  ]
}
```

### Linux:

```
curl -d
"{\"jsonrpc\": \"2.0\", \"id\": 1, \"method\": \"call\", \"params\": [\"5cd4b143b182
c07bc578ae3310d6280e\", \"file\", \"exec\", {\"command\": \"reboot\", \"params\": [
\"config\"]}]}" http://192.168.1.1/ubus
```

### Response:

The success response for this command is an empty message. If the response contains no data, the command was executed successfully.

## Set SIM card information

---

In this last example we'll try to change the mobile connection's MTU and Service mode values.

### Windows:

```
{
  "jsonrpc": "2.0", "id": 1, "method": "call", "params":
  [
    "558a9b03c940e52f373f8c02498952e3", "uci", "set",
    {
      "config": "simcard", "type": "sim1", "match":
      {
        "service": "auto",
        "mtu": "1500"
      },
      "values":
      {
        "service": "lte-only",
```

```
    "mtu":"1476"
  }
}
]
```

### Linux:

```
curl -d "{\"jsonrpc\":\"2.0\", \"id\":1, \"method\":\"call\",
\"params\": [\"558a9b03c940e52f373f8c02498952e3\", \"uci\", \"set\",
{\"config\":\"simcard\", \"type\":\"sim1\", \"match\":{\"service\":\"auto\",
\"mtu\":\"1500\"}, \"values\":{\"service\":\"lte-only\", \"mtu\":\"1476\"} }
] }" http://192.168.1.1/ubus
```

### Response:

```
{"jsonrpc":"2.0","id":1,"result":[0]}
```

The command used is *uci set* (highlighted in red). The config file name is **simcard**, section **sim1**, options **mtu** and **service** (configs, sections and options highlighted in orange). The response shown above is a positive response, but don't forget to execute *uci commit* and *luci-reload* afterwards or else your changes will not take effect.