

RUTC50 Realtime Data

[Main Page](#) > [RUTC Routers](#) > [RUTC50](#) > [RUTC50 Manual](#) > [RUTC50 WebUI](#) > [RUTC50 Status section](#) > **RUTC50 Realtime Data**

The information in this page is updated in accordance with firmware version [RUTC_R_00.07.07.1](#).

□

Contents

- [1 Summary](#)
- [2 Load](#)
- [3 Traffic](#)
- [4 Wireless](#)
- [5 Mobile Signal](#)
- [6 Mobile Usage](#)
- [7 Connections](#)

Summary

The **Realtime Data** page contains various graphs that display various statistical data changes in real time.

This chapter of the user manual provides an overview of the Realtime Data page for RUTC50 devices.

Load

The **Realtime Load** section displays a tri-graph that illustrates average CPU load values in real time. The graph consists out of three color coded graphs, each one corresponding to the average CPU load over 1 (red), 5 (orange) and 15 (yellow) most recent minutes.

The figure below is an example of the Realtime Load graph:

✘

Traffic

The **Realtime Traffic** graphs provide users with the possibility to monitor average inbound and outbound traffic over the course of 3 minutes. Each new measurement is taken every 3 seconds. The graphs consist out of two color coded graphs: the green graph shows the outbound traffic, the blue graph shows the inbound traffic. Although not graphed, the page also displays peak loads and averages of inbound and outbound traffic.

The figure below is an example of the Realtime traffic graph for the LAN connection: ✘

Graph	Description
LAN	Displays traffic that passes through the LAN network interface(s) in graph form
WAN, WAN6	Displays traffic that passes through the wired WAN connection in graph form
MOB1S1A1	Displays traffic that passes through the mobile WAN connection in graph form
RUT_XXXX_2G	Displays traffic that passes through the wifi connection in graph form

Wireless


The **Realtime Wireless** graph displays the wireless radio signal strength, signal noise, average and peak signal levels.

The figure below is example of Wireless graph:



Mobile Signal

The **Mobile Signal Strength** graph displays cellular signal strength value changes over time.

 To find more information on signal strength measurements, please visit the [Mobile Signal Strength Recommendations](#) page.

Mobile Usage

The **Mobile Usage** graph displays mobile data usage values over different periods of time.

You can navigate to different pages to display mobile data usage values over different periods of time. This includes:

- **Day** - data usage values for the current day
- **Week** - weekly data usage values
- **Month** - monthly data usage values
- **Total** - data usage for the entire monitoring period

The figure below is an example of the **Day** data usage graph:



Mobile data usage graphs for other periods of time are essentially identical, with the exception that different time units are displayed at the top of the graphs.

Below the graph you can see total data usage during specific data period.

Note: your carrier's data usage accounting may differ. Teltonika is not liable should any accounting discrepancies occur.

Connections

The **Realtime Connections** graph displays currently active network connections with the information about network, protocol, source, destination addresses and transfer speed. The table below the graph displays basic information on active connections.

The figures below are examples of both of the Realtime Connections graph and the corresponding

table: 