

# TCR100 VLAN

[Main Page](#) > [TCR Routers](#) > [TCR100](#) > [TCR100 Manual](#) > [TCR100 WebUI](#) > [TCR100 Network section](#) > **TCR100 VLAN**

The information in this page is updated in accordance with firmware version [TCR1\\_R\\_00.07.04.5](#).

□

## Contents

- [1 Summary](#)
- [2 Interface Based](#)
  - [2.1 Device Settings](#)
  - [2.2 Q-IN-Q Devices](#)

## Summary

A **Virtual LAN (VLAN)** is any broadcast domain that is partitioned and isolated in a computer network at the data link layer (OSI layer 2). LAN is the abbreviation for local area network and in this context virtual refers to a physical object recreated and altered by additional logic. VLANs work by applying tags to network packets and handling these tags in networking systems - creating the appearance and functionality of network traffic that is physically on a single network but acts as if it is split between separate networks. In this way, VLANs can keep network applications separate despite being connected to the same physical network, and without requiring multiple sets of cabling and networking devices to be deployed.

VLANs allow network administrators to group hosts together even if the hosts are not on the same network switch. This can greatly simplify network design and deployment, because VLAN membership can be configured through software. Without VLANs, grouping hosts according to their resource needs necessitates the labor of relocating nodes or rewiring data links. It also has benefits in allowing networks and devices that must be kept separate to share the same physical cabling without interacting, for reasons of simplicity, security, traffic management, or economy. For example, a VLAN could be used to separate traffic within a business due to users, and due to network administrators, or between types of traffic, so that users or low priority traffic cannot directly affect the rest of the network's functioning. Many Internet hosting services use VLANs to separate their customers' private zones from each other, allowing each customer's servers to be grouped together in a single network segment while being located anywhere in their datacenter. Some precautions are needed to prevent traffic "escaping" from a given VLAN, an exploit known as VLAN hopping.

This chapter is an overview of the VLAN section for TCR100 devices.

If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Basic" button under "Mode", which is located at the top-right corner of the WebUI.

## Interface Based

This section is an overview of created VLAN Devices.

### ^ INTERFACE BASED VLAN

DEVICE NAME	TAG	TYPE	INTERFACE
Example	3	802.1AD	eth0



### ^ ADD NEW INSTANCE

NEW DEVICE NAME

ADD

SAVE & APPLY

## Device Settings

The **Device Settings** section is used to configure the main parameters of a Q-in-Q device. Refer to the tables below for information on the configuration fields in the Q-in-Q Device Settings section.

### ^ DEMO DEVICE SETTINGS

Tag

Type

Interface

Field	Value	Description
Tag	[1..4094]; default: <b>none</b>	802.1 VLAN tag.
Type	802.1AD   802.1Q; default: <b>802.1AD</b>	The type of this Device.
Interface	ethernet network interface; default: <b>eth0</b>	Ethernet network interface associated with this Device. Network interfaces can be configured in the Network → <a href="#">Interfaces</a> page.

## Q-IN-Q Devices

**Q-in-Q** VLAN tunnel enables a possibility to segregate the traffic of different users in their infrastructure, while still giving a full range of VLANs for their internal use by adding a second tag to an already tagged frame.

By default the Q-in-Q Devices list is empty. To create a new Q-in-Q Device, enter as custom name for

it and click the 'Add' button. After this you will be able to configure it's 802.1Q Tag and Tagged interface.

^ Q-IN-Q DEVICES

---

DEVICE NAME

802.1Q TAG

Demo



^ ADD NEW DEVICE

---

NEW DEVICE NAME

ADD

< BACK

SAVE & APPLY

Field	Value	Description
802.1Q Tag [1..4094]; default:	<b>none</b>	802.1Q VLAN tag.