

# RUT140 VRF

[Main Page](#) > [RUT Routers](#) > [RUT140](#) > [RUT140 Manual](#) > [RUT140 WebUI](#) > [RUT140 Network section](#) > **RUT140 VRF**

The information in this page is updated in accordance with firmware version [RUT14X\\_R\\_00.07.07.3](#).

□

## Contents

- [1 Summary](#)
- [2 VRF](#)
  - [2.1 VRF configuration](#)

## Summary

Virtual routing and forwarding (VRF) is a technology included in Internet Protocol (IP) network routers that enables multiple instances of a routing table to exist in a virtual router and work simultaneously. This functionality increases connectivity by enabling network paths to be segmented without using multiple devices. VRF acts as a logical router. But, while a logical router may include many routing tables, a VRF instance uses only a single VRF table.

**Note:** Internet status is additional software that can be installed from the **System** → [Package Manager](#) page.

---

If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.

✘

## VRF

The **VRF** page is used to set up VRF instances.

To add a new instance - enter 'VRF name' below to the **Add New Instance** section and click 'Add' button:

✘

After clicking 'Add' you will be redirected to the newly added VRF instance configuration page.

## VRF configuration

✘

| <b>Field</b> | <b>Value</b>  | <b>Description</b>  |
|--------------|---|---|
| Enable       | off   on; default: <b>off</b>                               | Turns VRF instance on or off.   |
| Table        | integer [1..253 - 255..4294967295];<br>default: <b>none</b> | Unique routing table. 253-255 range is reserved for the default routing tables. |
| Link         | physical interface; default: <b>none</b>                    | Devices which will be used for routing and forwarding.                          |