RUT360 Dynamic DNS

<u>Main Page</u> > <u>RUT Routers</u> > <u>RUT360</u> > <u>RUT360 Manual</u> > <u>RUT360 WebUI</u> > <u>RUT360 Services section</u> > **RUT360 Dynamic DNS**

The information in this page is updated in accordance with firmware version **RUT36X R 00.07.08.2**.

Contents

- 1 Summary
- 2 Dynamic DNS Overview
- 3 Editing a DDNS instance
 - 3.1 cloudflare.com
- 4 See also

Summary

Dynamic DNS (**DDNS** or **DynDNS**) is a method of automatically updating a name server in the Domain Name System (DNS). This is most often utilized when the end user has a <u>dynamic IP address</u> and wants to bind it to a static hostname.

The device is compatible with many different third party DNS services that provide the possibility to create a custom hostname and bind it to an IP address. The DDNS service periodically updates the IP address information of the hostname, making sure that the device remains reachable via the same hostname even in cases when its IP address has changed.

This chapter is an overview of the Dynamic DNS section for RUT360 devices.

Note: Dynamic DNS is additional software that can be installed from the **System** → **Package Manager** page.

Dynamic DNS Overview

By default, an unconfigured DDNS instance will be present in the **Dynamic DNS Overview** page (the figure below is an example of this). You can create more DDNS instances by entering a name and clicking the "Add" button or you can edit the existing instance since it is not operational by default.



Editing a DDNS instance

To configure a DDNS instance, click the "Edit" button located next to it.

The figure below is an example of the edit page of the default DDNS instance called "MyDDNS" (already present in the device by default) and the table below provides information on the configuration fields contained in that page:



Field	Value	Description
Enabled	off on; Default: off	Turns the DDNS instance on or off.
Lookup hostname	host; Default: yourhost.example.com	Fully qualified domain name (FQDN) of your defined host. This is required to verify what the hostname's current IP address at DNS is (using <i>nslookup/host</i> command).
DDNS service provider	third party DNS service (chosen from list*) custom; Default: dyn.com	Third party DNS service provider.
Domain	host; Default: yourhost.example.com	Hostname that will be linked with the device IP address.
Username	string; Default: your_username	User name required to login to the third party DNS service; used to periodically login to your DNS service account and make necessary updates.
Password	string; Default: your_password	Password required to login to the third party DNS service; used to periodically login to your DNS service account and make necessary updates.
IP address source	Custom Public Private Script; Default: Custom	Defines the source to read the system's IPv4-Address from, that will be sent to the DNS provider. For example, if your device has a Private IP (i.e., 10.140.56.57) on its WAN interface, then you can send this exact IP to DDNS server by selecting <i>Private</i> .
Network	network interface; Default: lan	Specifies which interface's IP address should be bound to the hostname
Check Interval	integer [53600]; Default: 10 integer [3003600]* integer [13600]**	Frequency at which the device will check whether it's IP address has changed. The minimal amount of time that can be specified is 5 minutes or 300 seconds. *If selected interval is Seconds. **If selected interval is Hours.
Force Interval	integer [53600]; Default: 10 integer [13600]*	Frequency at which IP update requests are sent to the DNS provider. The minimal amount of time that can be specified is 5 minutes and not less than Check Interval . *If selected interval is Hours or Days.

binero.se changeip.com cloudflare.com-v4 core-networks.de ddns.com.br ddnss.de ddo.jp desec.io dhis.org $\underline{dnsdynamic.org}$ dnsever.com dnsexit.com dnshome.de dnsmadeeasy.com dnsmax.com dnsomatic.com dnspark.com do.de domopoli.de dtdns.com duckdns.org duiadns.net dy.fi dyn.com dyndns.it dyndns.org dyndnss.net dyns.net dynsip.org dynu.com dynv6.com easydns.com editdns.net goip.de google.com he.net joker.com loopia.se mydns.jp mvip.com.ua myonlineportal.net mythic-beasts.com namecheap.com nettica.com noip.com no-ip.pl now-dns.com nsupdate.info selfhost.de reafish.de schokokeks.org nubem.com opendns.com orav.com ovh.com secure.camera sitelutions.com spdns.de spdyn.de strato.com system-ns.com thatip.com twodns.de umedia.de variomedia.de xlhost.de zerigo.com zoneedit.com 7777.jo

cloudflare.com

Note: To use subdomains with **Cloudfare** services, you must use the @ symbol.

service_name cloudflare.com-v4

domain [Your domain, here: example.com]

username Bearer

password [Your API token]

To use subdomains (CNAME or A records), use the format below when filling your credentials:

domain {subdomain}@[zone]

Examples:

If the hostname is "sample.example.com", the "domain" field would be "sample@example.com"

If the hostname is "dev1.sample.example.com", the "domain" field would be "dev1.sample@example.com"

If using Cloudflare's "Subdomain Support", your zone may already be "foo.example.com", so if the DDNS hostname is "bar.foo.example.com" the domain field would be "bar@foo.example.com"

See also

- Dynamic DNS configuration examples for specific providers:
 - noip.com
 - dnsdynamic.org
 - dynu.com
 - dyn.com