

RUT950 Wake on LAN (legacy WebUI)

[Main Page](#) > [RUT Routers](#) > [RUT950](#) > [RUT950 Manual](#) > [RUT950 Legacy WebUI](#) > [RUT950 Services section \(legacy\)](#) > **RUT950 Wake on LAN (legacy WebUI)**

The information in this page is updated in accordance with firmware version [RUT9XX_R_00.06.09.5](#).

Note: this user manual page is for RUT950's old WebUI style available in earlier FW versions. [Click here](#) for information based on the latest FW version.

□

Contents

- [1 Summary](#)
- [2 Wake on LAN configuration](#)
- [3 Devices to wake up](#)
- [4 See also](#)

Summary

Wake on LAN (WOL) is feature that can "wake up" compliant computers from sleep mode by sending a "magic packet" to the network interface adapter.

This chapter of the user manual provides an overview of the Wake on LAN page for RUT950 devices.

Wake on LAN configuration

You can set up the WOL function to use a broadcast address when waking up devices or wake all connected devices on click from the **Wake on LAN configuration** section.

✘

Field	Value	Description
Broadcast	yes no; default: no	If checked, the WOL function sends a magic packet to the broadcast address (FF:FF:FF:FF:FF:FF) whenever it is asked to wake a device. When you send a packet to the broadcast address it is received by all LAN devices.
Wake all devices	- (interactive button)	Wakes all devices by sending a magic packet to the broadcast address (FF:FF:FF:FF:FF:FF).

Devices to wake up

The **Devices to wake up** section is used to configure entries for LAN devices that can later be woken up by the WOL function. Refer to the figure below for information on the fields contained in the Devices to wake up section.



Field name	Value	Description
Name	string; default: example	A custom name for the device. Only used for easier management purposes.
MAC	mac; default: 11:22:33:44:55:66	MAC address of the network interface card of the computer that will be "woken up".
Password	string; default: AABBCCDDEEFF	SecureON Password - sends given password when attempting to wake the host. Some computers have a BIOS feature that secures the WOL feature with a password. If your BIOS does not require such a password, leave this field empty.
Wake on Boot	yes no; default: no	Indicates whether the device should be "woken up" on router startup.
Wake device	- (interactive button)	Sends a magic packet to the specified device.
Delete	- (interactive button)	Deletes the device configuration.

See also

- [Wake on LAN PC configuration instructions](#)