

https://wiki.teltonika-networks.com/view/RUT956_%E3%82%AF%E3%82%A4%E3%83%83%E3%82%AF%E3%83%BB%E3%82%B9%E3%82%BF%E3%83%BC%E3%83%88%E3%83%BB%E3%82%AC%E3%82%A4%E3%83%89

RUT956

[Main Page](#) > [RUT Routers](#) > [RUT956](#) > [QSG RUT956](#) > **RUT956**

[English](#)

[日本語](#)

Wiki RUT956 LTE QSG RUT956

Contents

- [1](#)
- [1.1](#)
- [1.2 RF](#)
- [1.3](#)
- [1.4](#)
- [1.5](#)
- [1.6](#)
- [1.7 RUT956 RUT955](#)
- [2](#)
- [3](#)
- [4](#)
- [5](#)
- [6 Windows](#)
- [7](#)
- [8 SIM](#)

RF

2G, 3G, 4G, WiFi, GNSS

RF

33 dBm@GSM, 24 dBm@WCDMA, 23 dBm@LTE, 20 dBm@WiFi

0.45A@100-240 VAC, 9 VDC, 1A, 4-pin

698~960/1710~2690 MHz, 50 Ω, VSWR<3, 4dBi, SMA

WiFi

WiFi 2400~2500 MHz, 50Ω, VSWR<2, 3dBi, RP-SMA

GNSS

1575.42-1602 MHz, 2.2-5 VDC, VSWR<1.5, 28 dB (typ.), SMA



Windows

1. Enable Start -> Control Panel -> Network and Internet -> Network and Sharing Center -> Change adapter setting -> Wireless Network Adapter -> Enable



2. IP/DNS Wireless Network Adapter -> Properties -> Internet Protocol Version 4 -> Properties -> obtain an IP address automatically -> obtain DNS server address automatically -> OK



4. Wireless Network Adapter -> Connect



5. RUT956 *** -> Connect -> WiFi



1. URL http://192.168.1.1 WebUI



2. admin

3. WebUI



4. Configuration Wizard

5. Status -> Network -> Signal Strength

SIM

- SIM
- Industrial Grade SIM cards