

RUTX14 Traffic Logging

[Main Page](#) > [RUTX Routers](#) > [RUTX14](#) > [RUTX14 Manual](#) > [RUTX14 WebUI](#) > [RUTX14 Services section](#) > **RUTX14 Traffic Logging**

The information in this page is updated in accordance with firmware version [RUTX_R_00.07.08](#).

□

Contents

- [1 Summary](#)
- [2 Traffic Logging Settings](#)
- [3 FTP Settings](#)
 - [3.1 FTP Server](#)
 - [3.2 Upload Settings](#)

Summary

The **Traffic Logging** page provides the possibility to set up a periodic transfers of the selected traffic log to an FTP server.

This manual page provides an overview of the Traffic Logging page in RUTX14 devices.

Traffic Logging Settings

The **Traffic Logging Settings** section is used enable or disable traffic log data sending.



Field	Value	Description
Enable	off on; default: off	Turns Traffic Logging on or off.
Networks	network(s); default: lan	Selects the network(s) from which traffic logging data will be taken.

FTP Settings

The **FTP Settings** section is used to configure FTP server and upload settings.

FTP Server

The **FTP Server** section is used to configure the parameters required to login to an FTP server to which the traffic log data will be sent. Below is an example of the FTP Server section.



Field	Value	Description
Server address	ip host; default: none	FTP server's IP address or hostname.
User name	string; default: none	Username required for authentication to the FTP server.
Require Password	on off; default: off	Turns password requirement on or off.
Password	string; default: none	Password required for authentication to the FTP server.
Port	integer [0..65535]; default: 21	FTP server port.

Upload Settings

The **Upload Settings** section is used to configure how often the data should be sent to an FTP server. Below is an example of the FTP Server section:



Field	Value	Description
File name extras	No extra information MAC address Serial number Custom string; default: No extra information	Adds extra information to the log file names before uploading. The intention is to make it easier to differentiate files by their names.
Mode	Interval Fixed ; default: Interval	Upload mode. <ul style="list-style-type: none">• Interval - sends data at a specified frequency (for example, every 1 hour);• Fixed - sends data at a specified time of day (for example, at 2:25 a.m.)
Upload interval	1 hour 2 hours 4 hours 8 hours 12 hours 24 hours; default: 1 hour	Data upload frequency in hours.
Hours	integer [0..23]; default: none	Data upload will be performed at specific time of the day.
Minutes	integer [0..59]; default: none	Data upload will be performed at specific time of the day.
Days	Monday Tuesday Wednesday Thursday Friday Saturday Sunday; default: all	Specifies on which days of the week the data will be sent.