

TRB141 VRF

[Main Page](#) > [TRB Gateways](#) > [TRB141](#) > [TRB141 Manual](#) > [TRB141 WebUI](#) > [TRB141 Network section](#) > **TRB141 VRF**

The information in this page is updated in accordance with firmware version [TRB1_R_00.07.08](#).

□

Contents

- [1 Summary](#)
- [2 VRF](#)
 - [2.1 VRF configuration](#)

Summary

Virtual routing and forwarding (VRF) is a technology included in Internet Protocol (IP) network routers that enables multiple instances of a routing table to exist in a virtual router and work simultaneously. This functionality increases connectivity by enabling network paths to be segmented without using multiple devices. VRF acts as a logical router. But, while a logical router may include many routing tables, a VRF instance uses only a single VRF table.

Note: Internet status is additional software that can be installed from the **System** → [Package Manager](#) page.

If you're having trouble finding this page or some of the parameters described here on your device's WebUI, you should **turn on "Advanced WebUI" mode**. You can do that by clicking the "Advanced" button, located at the top of the WebUI.

✘

VRF

The **VRF** page is used to set up VRF instances.

To add a new instance - enter 'VRF name' below to the **Add New Instance** section and click 'Add' button:

✘

After clicking 'Add' you will be redirected to the newly added VRF instance configuration page.

VRF configuration

✘

| Field | Value | Description |
|--------------|---|---|
| Enable | off on; default: off | Turns VRF instance on or off. |
| Table | integer [1..253 - 255..4294967295]; default: none | Unique routing table. 253-255 range is reserved for the default routing tables. |
| Link | physical interface; default: none | Devices which will be used for routing and forwarding. |