

# TRB255 TR-069

[Main Page](#) > [TRB Gateways](#) > [TRB255](#) > [TRB255 Manual](#) > [TRB255 WebUI](#) > [TRB255 Services section](#) > **TRB255 TR-069**

The information in this page is updated in accordance with firmware version [TRB2\\_R\\_00.07.07.1](#).



## Contents

- [1 Summary](#)
- [2 TR-069 Client Configuration](#)
- [3 Management via TR-069](#)

## Summary

**TR-069 (Technical Report 069)** is an application layer protocol designed for management of equipment connected to a remote network.

This chapter of the user manual provides an overview of the UPnP page in TRB255 devices.

---

TR-069 is additional software that can be installed from the **System** → [Package Manager](#) page.

## TR-069 Client Configuration



| Field                 | Value                                      | Description   |
|-----------------------|--|---|
| Enable                | off   on; default: <b>off</b>              | Turns TR-069 client on or off.                                    |
| Periodic enable       | off   on; default: <b>on</b>               | Turns periodic data transmissions to server on or off.            |
| Accept server request | off   on; default: <b>off</b>              | When enabled the device accepts connection requests from servers. |
| Sending interval      | integer [60..9999999]; default: <b>100</b> | Periodic data transmission frequency (in seconds).                |
| Username              | string; default: <b>easycwmp</b>           | Username used for authentication to a TR-069 server.              |
| Password              | string; default: <b>easycwmp</b>           | Password used for authentication to a TR-069 server.              |

|     |   |   |
|-----|---|---|
| URL | host   ip; default:<br><b>http://192.168.1.110:8080/openacs/acs</b> | IP address or hostname of a<br>TR-069 server. |
|-----|---|---|

## Management via TR-069

TR-069 can be used to set or get values from RUT devices. Below is a list of commands used for device management via TR-069.

- R - read only;
- RW - read/write;
- string(64) - 64 bit string;
- string(256) - 256 bit string;
- unsignedInt - integer storing only positive values.

---

### Device Information:

1. **DeviceInfo.HardwareVersion** - device hardware version (e.g., 0201) R
2. **DeviceInfo.Manufacturer** - device manufacturer (e.g., Teltonika) R
3. **DeviceInfo.ManufacturerOUI** - organizationally unique identifier of the device manufacture (e.g., 001E42) R
4. **DeviceInfo.ProductClass** - device model (e.g., TRB255) R
5. **DeviceInfo.ProvisioningCode** - provisioning code
6. **DeviceInfo.SerialNumber** - device serial number (e.g., 1000111111) R
7. **DeviceInfo.SoftwareVersion** - device software version (e.g., TRB2\_R\_00.0X.XX) R
8. **DeviceInfo.SpecVersion** - device special version (e.g., 1.0) R

---

### Device GPS Information:

1. **GPSInfo.Latitude** - latitude coordinates of the device (e.g., 0.000000) R
2. **GPSInfo.Longitude** - longitude coordinates of the device (e.g., 0.000000) R

---

### Device Mobile Information:

1. **MobileInfo.Modem.1-1.CellID** - cell ID
2. **MobileInfo.Modem.1-1.ConnState** - connection state (e.g., Connected) R
3. **MobileInfo.Modem.1-1.ConnType** - connection type (e.g., LTE) R
4. **MobileInfo.Modem.1-1.EARFCN** - absolute radio frequency channel number (e.g., 75) R
5. **MobileInfo.Modem.1-1.ECIO** - signal, measured in dB R
6. **MobileInfo.Modem.1-1.ICCID** - SIM ICCID R
7. **MobileInfo.Modem.1-1.IMEI** - modem IMEI R
8. **MobileInfo.Modem.1-1.IMSI** - international mobile subscriber identity R
9. **MobileInfo.Modem.1-1.LAC** - location area code R
10. **MobileInfo.Modem.1-1.Manufacture** - modem manufacture R
11. **MobileInfo.Modem.1-1.Model** - modem model R
12. **MobileInfo.Modem.1-1.NeighbourCells** - neighbour cells (e.g., intra,LTE,75,109,-13,-104,-71,0,23,5,12,10,255) R

13. **MobileInfo.Modem.1-1.NetState** - operator state (e.g., Registered, home) R
  14. **MobileInfo.Modem.1-1.Operator** - operator name R
  15. **MobileInfo.Modem.1-1.OperatorNum** - operator number R
  16. **MobileInfo.Modem.1-1.PCI** - physical cell identity R
  17. **MobileInfo.Modem.1-1.PinState** - pin state (e.g., OK) R
  18. **MobileInfo.Modem.1-1.RSCP** - signal, measured in dBm R
  19. **MobileInfo.Modem.1-1.RSRP** - signal, measured in dBm R
  20. **MobileInfo.Modem.1-1.RSRQ** - signal, measured in dB R
  21. **MobileInfo.Modem.1-1.RSSI** - signal, measured in dBm R
  22. **MobileInfo.Modem.1-1.ReceivedThisMonth** - data received this month R
  23. **MobileInfo.Modem.1-1.ReceivedToday** - data received today R
  24. **MobileInfo.Modem.1-1.Revision** - modem firmware R
  25. **MobileInfo.Modem.1-1.SINR** - signal, measured in dB R
  26. **MobileInfo.Modem.1-1.SentThisMonth** - data sent this month R
  27. **MobileInfo.Modem.1-1.SentToday** - data sent today R
  28. **MobileInfo.Modem.1-1.Serial** - modem serial number R
  29. **MobileInfo.Modem.1-1.SimState** - sim state (e.g., Inserted) R
  30. **MobileInfo.Modem.1-1.TAC** - tracking area code R
  31. **MobileInfo.Modem.1-1.Temperature** - modem temperature R
- 

#### Device IP interface information:

1. **IP.Interface.1.Enable** - interface enabled/disabled (e.g., true) R
  2. **IP.Interface.1.IPv4Address.1.Enable** - IPv4 address enabled/disabled (e.g., 1) R
  3. **IP.Interface.1.IPv4Address.1.IPAddress** - IPv4 address (e.g., 192.168.1.1) R
  4. **IP.Interface.1.Name** - interface name (e.g., lan) R
- 

#### Device Management Server information:

1. **ManagementServer.ConnectionRequestPassword** - connection request password (e.g., randompassword) R
  2. **ManagementServer.ConnectionRequestURL** - connection request URL R
  3. **ManagementServer.ConnectionRequestUsername** - connection request username (e.g., 001E42-RUTX14-0000000000) R
  4. **ManagementServer.ParameterKey** -
  5. **ManagementServer.Password** -
  6. **ManagementServer.PeriodicInformEnable** - enabled/disabled TR-069 client periodic data transmission to TR-069 server (e.g., true) R
  7. **ManagementServer.PeriodicInformInterval** - periodic data transmission interval (e.g., 300) R
  8. **ManagementServer.PeriodicInformTime** - periodic information time (e.g., 1/1/1970, 8:09:27 PM) R
  9. **ManagementServer.URL** - server URL R
  10. **ManagementServer.Username** - server username R
- 

#### Device ID information:

1. **DeviceID.ID** - device ID (e.g., 001E42-RUTX14-0000000000) R
  2. **DeviceID.Manufacturer** - device manufacturer (e.g., Teltonika) R
  3. **DeviceID.OUI** - organizationally unique identifier of the device manufacture (e.g., 001E42) R
  4. **DeviceID.ProductClass** - product class (e.g., RUTXXX) R
  5. **DeviceID.SerialNumber** - device serial number R
- 

#### **Events information:**

1. **Events.0\_BOOTSTRAP** - bootstrap time R
2. **Events.1\_BOOT** - boot time R
3. **Events.Inform** - information time R
4. **Events.Registered** - events reg time R