

# TRB500 Dynamic DNS

[Main Page](#) > [TRB Gateways](#) > [TRB500](#) > [TRB500 Manual](#) > [TRB500 WebUI](#) > [TRB500 Services section](#) > **TRB500 Dynamic DNS**

The information in this page is updated in accordance with firmware version [TRB5\\_R\\_00.07.07.1](#)

**Note: Firmware versions before TRB5\_R\_00.07.04.4 will not be supported by devices from batch 09 and higher..**



## Contents

- [1 Summary](#)
- [2 Dynamic DNS Overview](#)
- [3 Editing a DDNS instance](#)
  - [3.1 cloudflare.com](#)
- [4 See also](#)

## Summary

**Dynamic DNS (DDNS or DynDNS)** is a method of automatically updating a name server in the Domain Name System (DNS). This is most often utilized when the end user has a [dynamic IP address](#) and wants to bind it to a static hostname.

The device is compatible with many different third party DNS services that provide the possibility to create a custom hostname and bind it to an IP address. The DDNS service periodically updates the IP address information of the hostname, making sure that the device remains reachable via the same hostname even in cases when its IP address has changed.

This chapter is an overview of the Dynamic DNS section for TRB500 devices.

## Dynamic DNS Overview

By default, an unconfigured DDNS instance will be present in the **Dynamic DNS Overview** page (the figure below is an example of this). You can create more DDNS instances by entering a name and clicking the "Add" button or you can edit the existing instance since it is not operational by default.



# Editing a DDNS instance

To configure a DDNS instance, click the "**Edit**" button located next to it.

The figure below is an example of the edit page of the default DDNS instance called "MyDDNS" (already present in the device by default) and the table below provides information on the configuration fields contained in that page:



Field	Value	Description
Enabled	off   on; Default: <b>off</b>	Turns the DDNS instance on or off.
Lookup hostname	host; Default: <b>yourhost.example.com</b>	Fully qualified domain name (FQDN) of your defined host. This is required to verify what the hostname's current IP address at DNS is (using <i>nslookup/host</i> command).
DDNS service provider	third party DNS service (chosen from list*)   -- custom --; Default: <b>dyn.com</b>	Third party DNS service provider.
Domain	host; Default: <b>yourhost.example.com</b>	Hostname that will be linked with the device IP address.
Username	string; Default: <b>your_username</b>	User name required to login to the third party DNS service; used to periodically login to your DNS service account and make necessary updates.
Password	string; Default: <b>your_password</b>	Password required to login to the third party DNS service; used to periodically login to your DNS service account and make necessary updates.
IP address source	Custom   Public   Private   Script; Default: <b>Custom</b>	Defines the source to read the system's IPv4-Address from, that will be sent to the DNS provider. For example, if your device has a Private IP (i.e., 10.140.56.57) on its WAN interface, then you can send this exact IP to DDNS server by selecting <i>Private</i> .
Network	network interface; Default: <b>lan</b>	Specifies which interface's IP address should be bound to the hostname
Check Interval	integer [5..3600]; Default: <b>10</b> integer [300..3600]* integer [1..3600]**	Frequency at which the device will check whether it's IP address has changed. The minimal amount of time that can be specified is 5 minutes or 300 seconds. *If selected interval is Seconds. **If selected interval is Hours.
Force Interval	integer [5..3600]; Default: <b>10</b> integer [1..3600]*	Frequency at which IP update requests are sent to the DNS provider. The minimal amount of time that can be specified is 5 minutes and not less than <b>Check Interval</b> . *If selected interval is Hours or Days.

\* Supported DNS services

binero.se	changeip.com	cloudflare.com-v4	core-networks.de	ddns.com.br	ddnss.de	ddo.jp	desec.io
dhis.org	<a href="https://dnshack.com">dnshack.com</a>	dnserver.com	dnsexit.com	dnshome.de	dnsmadeeasy.com	dnsmax.com	dnsomatic.com
dnspark.com	do.de	domopoli.de	dtDNS.com	duckdns.org	duiads.net	dy.fi	<a href="https://dyn.com">dyn.com</a>
dyndns.it	dyndns.org	dyndns.net	dyns.net	dynsip.org	<a href="https://dynu.com">dynu.com</a>	dynv6.com	easydns.com
editdns.net	goip.de	google.com	he.net	joker.com	loopia.se	mydns.jp	myip.com.ua
myonlineportal.net	mythic-beasts.com	namecheap.com	nettica.com	<a href="https://noip.com">noip.com</a>	no-ip.pl	now-dns.com	nsupdate.info
nubem.com	opendns.com	oray.com	ovh.com	regfish.de	schokoeks.org	secure.camera	selfhost.de
sitelutions.com	spdns.de	spdyn.de	strato.com	system-ns.com	thatip.com	twodns.de	umedia.de
variomedia.de	xlhost.de	zerigo.com	zoneedit.com	zzzz.io			

## cloudflare.com

**Note:** To use subdomains with **Cloudflare** services, you must use the @ symbol.

service_name	cloudflare.com-v4
domain	[Your domain, here: example.com]
username	Bearer
password	[Your API token]

To use subdomains (CNAME or A records), use the format below when filling your credentials:

domain	{subdomain}@[zone]
--------	--------------------

Examples:

If the hostname is “sample.example.com”, the “domain” field would be “sample@example.com”

If the hostname is “dev1.sample.example.com”, the “domain” field would be “dev1.sample@example.com”

If using Cloudflare's “Subdomain Support”, your zone may already be “foo.example.com”, so if the DDNS hostname is “bar.foo.example.com” the domain field would be “bar@foo.example.com”

## See also

- Dynamic DNS configuration examples for specific providers:
  - [noip.com](https://noip.com)
  - [dnshack.com](https://dnshack.com)
  - [dynu.com](https://dynu.com)
  - [dyn.com](https://dyn.com)