

# Template:Networking tswos manual snmp

The information in this page is updated in accordance with firmware version .



## Contents

- [1 Summary](#)
- [2 SNMP settings](#)
  - [2.1 SNMP agent settings](#)
  - [2.2 SNMP System Summary](#)
- [3 SNMP v3 users](#)
- [4 Communities](#)
- [5 SNMP variables list](#)

## Summary

**Simple Network Management Protocol (SNMP)** is a network management protocol used for collecting information and configuring network devices. This page is an overview of the SNMP function in {{name}} devices.

## SNMP settings

The **SNMP settings** page is used to configure SNMP accessibility and general SNMP information for your device.

### SNMP agent settings



Field	Value	Description
Enable SNMP service	off   on; default: <b>off</b>	Enable SNMP (Simple Network Management Protocol) service on systems startup.
IP type	IPv4   IPv6   IPv4v6; default: <b>IPv4</b>	IP type used by SNMP.
Port	integer [0..65535]; default: <b>161</b>	TCP/UDP port number used for the connection.
SNMP v1 Mode	off   on; default: <b>on</b>	Enable SNMP v1 compatibility.
SNMP v2c Mode	off   on; default: <b>on</b>	Enable SNMP v2 compatibility.
SNMP v3 Mode	off   on; default: <b>off</b>	Enable SNMP v3 compatibility.

## SNMP System Summary

---

The **SNMP System Summary** section contains general information about SNMP on this device. You can also download this device's **MIB file** from this section.



Field	Value	Description
MIB file	-(interactive button)	Downloads the device's MIB file.
System OID	1.3.6.1.4.1.48690	An OID is an Object Identifier. It's an address used to identify devices and their statuses.
Location	string; default: <b>location</b>	Location of the system. If the field is empty, the option will have read-write permissions. If not, the option will become read-only.
Contact	string; default: <b>email@example.com</b>	Contact email. If the field is empty, the option will have read-write permissions. If not, the option will become read-only.
Name	string; default: <b>name</b>	Name of the system. If the field is empty, the option will have read-write permissions. If not, the option will become read-only.

## SNMP v3 users

The **SNMP v3 users** page is used to create and manage users, who can be authenticated using SNMP v3. To configure an SNMP user, you must first create it:

1. Enter a custom name for the new user in the 'Name' field.
2. Click the 'Add' button.
3. Click the 'Edit' button next to the newly created user.



---

The SNMP user configuration window should look similar to this:



**Note:** this table has coloring scheme to indicate which fields can be seen with different configuration.

Field	Value	Description
Enable	off   on; default: <b>off</b>	Enable SNMP user configuration.
Username	string; default: <b>none</b>	Set username to access SNMP.
Access Mode	Read-Only   Read-Write; default: <b>Read-Only</b>	The access mode specifies the access the hosts in the community are allowed with respect to retrieving and modifying the MIB variables from a specific SNMP agent.

MIB subtree	string; default: <b>none</b>	Leave empty to access full MIB tree.
Security level	No authentication, no privacy   <b>Authentication, no privacy</b>   <b>Authentication and privacy</b> ; default: <b>No authentication, no privacy</b>	A security level is an authentication strategy that is set up for the user. No authentication, no privacy - authenticates with a username. Authentication - provides MD5 or SHA algorithms for authentication. Privacy - Provides DES or AES encryption.
	<b>Authentication, no privacy</b>   <b>Authentication and privacy</b> : SHA   MD5; default: <b>SHA</b>	Set authentication type to use with SNMP v3.
Authentication type		
	<b>Authentication, no privacy</b>   <b>Authentication and privacy</b> : string; default: <b>none</b>	Set authentication passphrase to generate key for SNMP v3.
Authentication passphrase		
	<b>Authentication and privacy</b> : DES   AES; default: <b>DES</b>	Set privacy type to use with SNMP v3.
Privacy type		
	<b>Authentication and privacy</b> : string; default: <b>none</b>	Set privacy passphrase to generate key for SNMP v3.
Privacy passphrase		

## Communities

The **SNMP Community** section is used to manage access rights. You can edit an SNMP community by clicking the 'Edit' button next to it:



This will redirect you to the community's configuration page.



Field	Value	Description
Community name	string; default: <b>none</b>	Name of the community.
IP Address	ip; default: <b>none</b>	IP address of the community.
IP Mask	ip; default: <b>none</b>	Netmask for IP of the community.
Access Mode	Read-Only   Read-Write; default: <b>Read-Only</b>	Access mode for current community.

SNMPv6 community configuration page:



Field	Value	Description
Community name	string; default: <b>public</b>	Name of the community.
Source	ip6   domain name; default: <b>default</b>	Source of the community.
Access Mode	Read-Only   Read-Write; default: <b>Read-Only</b>	Access mode for current community.

# SNMP variables list

Name	OID	Description
<b>Device</b>		
serial	.1.3.6.1.4.1.48690.1.1.0	Device serial number
deviceName	.1.3.6.1.4.1.48690.1.2.0	Device name
productCode	.1.3.6.1.4.1.48690.1.3.0	Device product (ordering) code
batchNumber	.1.3.6.1.4.1.48690.1.4.0	Device batch number
hardwareRevision	.1.3.6.1.4.1.48690.1.5.0	Device hardware revision
fwVersion	.1.3.6.1.4.1.48690.1.6.0	Device firmware version
deviceUptime	.1.3.6.1.4.1.48690.1.7.0	Device uptime in seconds
cpuUsage	.1.3.6.1.4.1.48690.1.8.0	Device cpu usage in percents
<b>VLAN</b>		
pVlanCount	.1.3.6.1.4.1.48690.8.1.0	Amount of port-based virtual networks.
pVlanIndex	.1.3.6.1.4.1.48690.8.2.1.1	Index of port-based VLAN
pVlanName	.1.3.6.1.4.1.48690.8.2.1.2	Name of port-based VLAN
pVlanVID	.1.3.6.1.4.1.48690.8.2.1.3	VLAN ID of port-based VLAN
pVlanPortsUntag	.1.3.6.1.4.1.48690.8.2.1.4	Untagged ports of port-based VLAN
pVlanPortsTag	.1.3.6.1.4.1.48690.8.2.1.5	Tagged ports of port-based VLAN
<b>Iface</b>		
ifaceCount	.1.3.6.1.4.1.48690.11.1.0	Number of interfaces on the device
ifaceIndex	.1.3.6.1.4.1.48690.11.2.1.1	A unique value, greater than zero, for each interface
ifaceName	.1.3.6.1.4.1.48690.11.2.1.2	Interface's name
ifaceState	.1.3.6.1.4.1.48690.11.2.1.3	Indicates interface's operational state as a string
ifaceSpeed	.1.3.6.1.4.1.48690.11.2.1.4	Indicates the interface latest or current speed value. Value is an integer representing the link speed in Mbits/sec
ifaceMulticast	.1.3.6.1.4.1.48690.11.2.1.5	Interface's multicast
ifaceRDiscards	.1.3.6.1.4.1.48690.11.2.1.6	Interface's incoming discards
ifaceRErrors	.1.3.6.1.4.1.48690.11.2.1.7	Interface's incoming errors
ifaceRTraffic	.1.3.6.1.4.1.48690.11.2.1.8	Interface's incoming traffic count
ifaceTDiscards	.1.3.6.1.4.1.48690.11.2.1.9	Interface's outgoing discards
ifaceTErrors	.1.3.6.1.4.1.48690.11.2.1.10	Interface's outgoing errors
ifaceTTraffic	.1.3.6.1.4.1.48690.11.2.1.11	Interface's outgoing traffic count

[[Category:{{name}}] Services section]]