

Command Line Interfaces

[Main Page](#) > [FAQ](#) > [Control & Configuration](#) > **Command Line Interfaces**

□

Contents

- [1 Introduction](#)
- [2 CLI \(WebUI\)](#)
- [3 SSH](#)
 - [3.1 Linux](#)
 - [3.1.1 RSA key](#)
 - [3.2 Windows](#)
 - [3.2.1 RSA key](#)
- [4 RS232/RS485 console \(only with RUT955\)](#)
 - [4.1 Router configuration](#)
 - [4.2 Linux](#)
 - [4.3 Windows](#)
- [5 See also](#)
- [6 External links](#)

Introduction

A **command line interface (CLI)** is a means of interacting with a computer program or system where the user (or client) issues commands to the program in the form of successive lines of text (command lines). A program which handles the interface is called a **command language interpreter** or **shell**.

Teltonika-Networks devices support a variety of different command line interfaces all of which will be described in this article. Only the methods of reaching and logging in via a specified CLI will be described here and not any specific command usage.

In all cases, CLI login information for Teltonika-Networks devices routers is:

- User name: **root**
- Password: **router's admin password**

CLI (WebUI)

RUTxxx routers have a command line interface built-in to their **Web User Interfaces (WebUI)**. This is the most accessible method because all you need is web browser.

-
- Simply login to the WebUI by typing the router's LAN IP address into the URL field of your web browser and press "Enter" on your keyboard:



-
- After this, you will be greeted with the login window. Type in the user name **admin** and the router's admin password and click "Login":



-
- Then locate the CLI section under the System tab:



-
- Type in the login name *root*, press "Enter", type in the router's admin password and press "Enter" again. You should be greeted with a message such as this:



SSH

Secure Shell (SSH) is a cryptographic network protocol for operating network services securely over an unsecured network. The best known example application is for remote login to computer systems by users. The login process is different for different operating systems. Therefore, this section is split into two parts: **Linux** and **Windows**.

Linux

Linux operating systems support many applications that can be used to login to a RUTxxx router via SSH, but the most common is **Terminal**, which we'll be using for this example.

- Open a new Terminal window, type **ssh root@192.168.1.1** and press "Enter". If this is your first time logging in, you might be asked to clarify whether you really want to login. In that case, just type **yes** and press "Enter". Then type in the router's admin password and press "Enter" to finish the login process:



After this you should be greeted with a window such as the one depicted in the figure above.

RSA key

There is a possibility to use an RSA key instead of a password when logging in via SSH. This process is described [here](#) in detail.

Windows

To login to a RUTxxx router via SSH using a Windows OS you will need an SSH client application. The most common is **PuTTY** - free, open source SSH and Telnet client, which we'll be using for this example. You can download PuTTY from [here](#).

- Launch PuTTY and select the **SSH** option under the "Connection type" field. Type in the router's LAN IP address into the "Host Name (or IP address)" field, specify the SSH port into the "Port" field (**22** by default) and click "Open":



- In the next window type in the login name *root*, press "Enter", type in the router's admin password and press "Enter" again. You should be greeted with a message such as this:




- Newer Windows 10 editions already have a built in SSH client. see <https://docs.microsoft.com/en-us/windows/terminal/tutorials/ssh>
-


RSA key


There is a possibility to use an RSA key instead of a password when logging in via SSH. This process is described [here](#) in detail.

RS232/RS485 console (only with RUT955)

It is also possible to control a RUT955 router via RS232 or RS485 consoles. For this, however, you will need the adequate cables:

 Straight-through Female/Male RS232 cable

 Null-modem (crossed) Male/Male RS232 cable

 USB to RS232 (Male) cable

You can login to the RS485 console with a 2-wire cable. You can use the RS485 jack that comes with the router for one end; the other end of the cable basically depends on your end device's capabilities (it can be USB, RS232, etc.)

Router configuration

- The configuration for the router's side is fairly simple. Just login to the router's WebUI, go to **Services** → **RS232/RS485**, place a check mark next to the "Enable" field and select "Serial type: Console" (the same is true for both RS232 and RS485):



You can leave the rest of the settings as defaults or set them in accordance with your needs. Don't forget to click save after you have made the changes.

Linux

- To login from a Linux PC, you'll need an application for serial communication like **minicom** or **gtkterm**. For this example we'll be using minicom. You can download it by typing these lines into the Terminal:

```
$ sudo apt-get update
$ sudo apt-get install minicom
```

update downloads a list of newest software packages; **install minicom** downloads and installs minicom.

- Once you've installed minicom, you can run it with the command **sudo minicom** from the Linux Terminal. This will open a new console window where you will need to set some things up. Press **Ctrl + A** at once on your keyboard, then press "Z" which will direct you to the settings menu:



- Press "O" on your keyboard. This will direct you to the main settings menu. From there you should specify the name of the serial device and the same parameters that you entered in the router's configuration. A picture with corresponding parameters is presented below:

[File:Minicom settings port v2.png](#)

Once done, press "Enter". In the next menu you can save these settings as defaults by selecting **Save setup as dfl** so that you wouldn't need to set everything up the next time you use the console.

- Press "Esc" on your keyboard to return to the console window and type in the login name *root*, press "Enter", type in the router's admin password and press "Enter" again. After this, you will be able to use the RS232/RS485 console.

Windows

To login from a Windows PC, you'll need an application for serial communication. The most common is **PuTTY** - free, open source SSH and Telnet client, which we'll be using for this example. You can download PuTTY from [here](#).

- First you must find out which **Serial line** (or **COM port**) your cable uses. To do so, go to Windows **Device Manager** (you can find it easily via the search field or in the Control Panel). Find **Ports (COM & LPT)** in the device list and expand that section. Locate your serial device

(depends on the type of cable) and take note of its **COM port number** (**COM3** in our example):



-
- Launch PuTTY and select the **Serial** option under the "Connection type" field. Specify the COM port (**COM3** from our example) in the "Serial line" field and the Baud rate from your router's configuration in the "Speed" field (**115200** from our example) and click "Open":

[File:Putty serial login 2 v2.PNG](#)

- In the next window type in the login name *root*, press "Enter", type in the router's admin password and press "Enter" again. You should be greeted with a message such as this:

[File:Putty serial login 3 v2.PNG](#)

See also

- [SSH RSA key authentication \(Linux\)](#)
- [SSH RSA key authentication \(Windows\)](#)

External links

- <https://www.chiark.greenend.org.uk/~sgtatham/putty/latest.html> - PuTTY downloads page