

# RUT230 TR-069

[Main Page](#) > [RUT Routers](#) > [RUT230](#) > [RUT230 Manual](#) > [RUT230 WebUI](#) > [RUT230 Services section](#) > **RUT230 TR-069**

The information in this page is updated in accordance with firmware version [RUT2\\_R\\_00.07.03.4](#).

**Notice:** This device has entered it's EOL (End of Life) cycle. For more information, visit our EOL policy [here](#). Temporarily, some content in this page might not match features found in firmware listed above.



## Contents

- [1 Summary](#)
- [2 TR-069 Client Configuration](#)
- [3 Management via TR-069](#)

## Summary

**TR-069 (Technical Report 069)** is an application layer protocol designed for management of equipment connected to a remote network.

This chapter of the user manual provides an overview of the UPnP page in RUT230 devices.

---

TR-069 is additional software that can be installed from the **System** → [Package Manager](#) page.

## TR-069 Client Configuration



Field	Value	Description
Enable	off   on; default: <b>off</b>	Turns TR-069 client on or off.
Periodic enable	off   on; default: <b>on</b>	Turns periodic data transmissions to server on or off.
Accept server request	off   on; default: <b>off</b>	When enabled the device accepts connection requests from servers.
Sending interval	integer [60..9999999]; default: <b>100</b>	Periodic data transmission frequency (in seconds).
Username	string; default: <b>easycwmp</b>	Username used for authentication to a TR-069 server.

Password	string; default: <b>easycwmp</b>	Password used for authentication to a TR-069 server.
URL	host   ip; default: <b>http://192.168.1.110:8080/openacs/acs</b>	IP address or hostname of a TR-069 server.

## Management via TR-069

TR-069 can be used to set or get values from RUT devices. Below is a list of commands used for device management via TR-069.

- R - read only;
- RW - read/write;
- string(64) - 64 bit string;
- string(256) - 256 bit string;
- unsignedInt - integer storing only positive values.

---

### Device Information:

1. **DeviceInfo.Manufacturer** - device manufacturer (e.g., Teltonika) R
2. **DeviceInfo.ProductClass** - device model (e.g., RUT230) R
3. **DeviceInfo.SerialNumber** - device serial number (e.g., 1000111111) R
4. **DeviceInfo.UpTime** - device uptime R;

---

### Mobile Information:

1. **MobileInfo.ICCID** - SIM ICCID R;
2. **MobileInfo.Operator** - name of operator used R;
3. **MobileInfo.SentThisMonth** - bytes sent this month R;
4. **MobileInfo.ReceivedThisMonth** - bytes received this month R;