

# RUT300 TR-069

[Main Page](#) > [RUT Routers](#) > [RUT300](#) > [RUT300 Manual](#) > [RUT300 WebUI](#) > [RUT300 Services section](#) > **RUT300 TR-069**

The information in this page is updated in accordance with firmware version [RUT30X\\_R\\_00.07.06.10](#).



## Contents

- [1 Summary](#)
- [2 TR-069 Client Configuration](#)
- [3 Management via TR-069](#)

## Summary

**TR-069 (Technical Report 069)** is an application layer protocol designed for management of equipment connected to a remote network.

This chapter of the user manual provides an overview of the UPnP page in RUT300 devices.

---

TR-069 is additional software that can be installed from the **System** → [Package Manager](#) page.

## TR-069 Client Configuration



Field	Value	Description
Enable	off   on; default: <b>off</b>	Turns TR-069 client on or off.
Periodic enable	off   on; default: <b>on</b>	Turns periodic data transmissions to server on or off.
Accept server request	off   on; default: <b>off</b>	When enabled the device accepts connection requests from servers.
Sending interval	integer [60..99999999]; default: <b>100</b>	Periodic data transmission frequency (in seconds).
Username	string; default: <b>easycwmp</b>	Username used for authentication to a TR-069 server.
Password	string; default: <b>easycwmp</b>	Password used for authentication to a TR-069 server.

URL	host   ip; default: <b>http://192.168.1.110:8080/openacs/acs</b>	IP address or hostname of a TR-069 server.
-----	---	---

## Management via TR-069

TR-069 can be used to set or get values from RUT devices. Below is a list of commands used for device management via TR-069.

- R - read only;
- RW - read/write;
- string(64) - 64 bit string;
- string(256) - 256 bit string;
- unsignedInt - integer storing only positive values.

---

### Device Information:

1. **DeviceInfo.Manufacturer** - device manufacturer (e.g., Teltonika) R
2. **DeviceInfo.ProductClass** - device model (e.g., RUT300) R
3. **DeviceInfo.SerialNumber** - device serial number (e.g., 1000111111) R
4. **DeviceInfo.UpTime** - device uptime R;