

RUT301 OPC UA

[Main Page](#) > [RUT Routers](#) > [RUT301](#) > [RUT301 Manual](#) > [RUT301 WebUI](#) > [RUT301 Services section](#) > **RUT301 OPC UA**

The information in this page is updated in accordance with firmware version [RUT301_R_00.07.07.1](#).



Contents

- [1 Summary](#)
- [2 OPC UA Servers](#)
 - [2.1 OPC UA Server Configuration](#)
 - [2.2 OPC UA Server Nodes](#)
 - [2.2.1 OPC UA Server Node Configuration](#)
- [3 OPC UA Value Groups](#)
 - [3.1 OPC UA Value Group Configuration](#)
 - [3.2 OPC UA Group Values](#)
 - [3.2.1 OPC UA Group Value Configuration](#)

Summary

OPC Unified Architecture (**OPC UA**) is a cross-platform, open-source, IEC62541 standard for data exchange from sensors to cloud applications developed by the OPC Foundation. The *UA* in OPC UA stands for “Unified Architecture” and refers to the latest specification of the standard. It differs from its predecessor in that it is platform-independent, moving away from COM/DCOM to purely binary TCP/IP or alternatively SOAP.

This manual page provides an overview of the OPC UA functionality in RUT301 devices.

Note: OPC UA is additional software that can be installed from the **System** → [Package Manager](#) page.

OPC UA Servers

The OPC Server is the basis of OPC communication. It is a software that implements the OPC standard and thus provides the standardized OPC interfaces to the outside world.

Notice the Global section config. It is used to outright turn the service off or on if any active configurations are present.



Clicking the Cog icon opens a modal window. The global configuration slider can be set and it's state

saved.



To add a new server, enter an instance name and click the 'Add' button.

Note: A maximum of **10** servers is allowed.



After clicking 'Add' you will be redirected to the newly added server's configuration page.

OPC UA Server Configuration

The **OPC UA Server Configuration** section is used to configure the parameters of an OPC UA Server.



| Field | Value | Description |
|---------|---|--|
| Enable | off on; default: off | Enables specific OPC UA server instance. |
| Name | string; default: none | Name of the server, used for management purposes only. |
| URL | url; default: none | Specifies OPC UA endpoint URL. |
| Timeout | integer [10..3600000]; default: none | Specifies server timeout in ms. |

OPC UA Server Nodes

A node is the basic unit of data in the OPC UA address space, which provides a standard way for OPC UA servers to represent objects to OPC UA clients. Nodes are pieces of information (for example, a unique temperature) and consist of attributes, the actual data value, and one or more references to other nodes, each in its own address space. A unique temperature will therefore take up multiple addresses in an address space.



By default, there are no nodes configured. To add a new server node, enter an instance name and click the 'Add' button.


Note: A maximum of **50** nodes per server are allowed.



After clicking 'Add' you will be redirected to the newly added server node's configuration page.

OPC UA Server Node Configuration


The **OPC UA Server node Configuration** section is used to configure the parameters of an OPC UA Server Node.



| Field | Value | Description |
|--------------|---|---|
| Name | string; default: none | Name of the node instance, used for management purposes only. |
| ID namespace | integer [0..65535]; default: none | Specifies node ID namespace. |
| ID type | Numeric String GUID Bytestring; default: Numeric | Specifies node ID type. |
| ID | dynamic; default: none | Specifies node ID (validation varies depending on <i>ID type</i>). |


OPC UA Value Groups

A Value Group is a collection of different specific group values. Each value configured under this group will be returned inside the same group array.



By default, there are no value groups configured. To add a new group, enter an instance name and click the 'Add' button.


Note: A maximum of **20** value groups are allowed.



After clicking 'Add' you will be redirected to the newly added value group's configuration page.

OPC UA Value Group Configuration

The **OPC UA Value Group Configuration** section is used to configure the parameters of an OPC UA Value Group.



| Field | Value | Description |
|---------------------------------|---|--|
| Enable | off on; default: off | Enables specific OPC UA value group instance. |
| Name | string; default: none | Name of the value group instance, used for management purposes only. |
| Scheduling type | Period; default: Period | Specifies method of scheduling data retrievals. |
| Period | integer [1..86400]; default: none | Specifies time duration between data retrievals in seconds. |
| Failure mode | None Any All ; default: None | |
| Failure storage | off on; default: off | Whether to store results of a failure. |
| Failure replacement | string; default: none | Results of a failure will be replaced by this string |

| | | |
|---------|------------------------------|--------------------------------------|
| Prefix | string; default: none | String going before all the values. |
| Midfix | string; default: none | String going between all the values. |
| Postfix | string; default: none | String going after all the values. |

OPC UA Group Values

A **Group Value** is a specific value retrieved from a defined server node.



By default, there are no group values configured. To add a new value, enter an instance name and click the 'Add' button.

Note: A maximum of **50** values per value group is allowed.



After clicking 'Add' you will be redirected to the newly added group value's configuration page.

OPC UA Group Value Configuration

The **OPC UA Group Value Configuration** section is used to configure the parameters of an OPC UA Group Value.



| Field | Value | Description |
|------------------------------|---|--|
| Enable | off on; default: off | Enables specific OPC UA value instance. |
| Name | string; default: none | Name of the group value instance, used for management purposes only. |
| Prefix | string; default: none | String before the value. |
| Postfix | string; default: none | String after the value. |
| Replacement | string; default: none | String to replace everything in case of failure. |
| Server to retrieve data from | OPC UA server instance; default: none | Specifies which server to retrieve data from. |
| Server node | OPC UA server node instance; default: none | Specifies which server node to retrieve data from. |