

RUT955 NTP (legacy WebUI)

[Main Page](#) > [RUT Routers](#) > [RUT955](#) > [RUT955 Manual](#) > [RUT955 Legacy WebUI](#) > [RUT955 Services section \(legacy\)](#) > [RUT955 NTP \(legacy WebUI\)](#)

The information in this page is updated in accordance with firmware version [RUT9XX_R_00.06.09.5](#).

Note: this user manual page is for RUT955's old WebUI style available in earlier FW versions. [Click here](#) for information based on the latest FW version.



Contents

- [1 Summary](#)
- [2 General](#)
 - [2.1 NTP Server](#)
- [3 Time Servers](#)

Summary

Network Time Protocol (NTP) is a networking protocol for clock synchronization between computer systems over packet-switched, variable-latency data networks.

This chapter of the user manual provides an overview of the NTP page for RUT955 devices.

General

The **Time Synchronization** section is used to configure general router time settings, like selecting the local time zone, setting a time update interval, synchronizing the time and more.

The figure below is an example of the Time Synchronization section and the table below provides information about the fields contained in that section. 

Field	Value	Description
Current system time	time; default: none	Current local time of the router.
Time zone	time zone; default: UTC	The router will sync time in accordance with the selected time zone.
Enable NTP	yes no; default: yes	Turns NTP on or off.
Force servers	yes no; default: no	Forces unreliable NTP servers.
Update interval (in seconds)	integer; default: 3660	Defines how often the router will update the time.
Save time to flash	yes no; default: no	Saves last synchronized time to flash memory.

Count of time synchronizations	integer; default: none	The amount of times that router will perform time synchronizations. Leave empty in order to set to infinite.
Operator Station Synchronizations	yes no; default: no	Turns synchronization with mobile operator on or off.
Count of failed NTP requests	integer; default: none	The amount of times that router needs to fail to send NTP requests before launching operator station synchronization. Empty value - 5.
GPS synchronization	yes no; default: no	Enables periodic time synchronization for the system using the GPS module (does not require an Internet connection).
GPS time update interval	5, 30 minutes 1, 6, 12, 24 hours 1 week 1 month; default: Every 24 hours	Defines how often the router will update the time using the GPS module.
Offset frequency	integer; default: 0	Adjusts the minor drift of the clock so that it will run more accurately.

NTP Server

The router can also act as an **NTP Server**, providing clock synchronization to other devices in the network. From this section you can turn this feature on or off.



Time Servers

The **Time Servers** section displays the NTP servers that the router uses. You are provided with 4 default time servers (as seen in the example below), but you can also add custom time servers by clicking the 'Add' button or you can edit the given time servers.

