

# TRB500 OPC UA Server

[Main Page](#) > [TRB Gateways](#) > [TRB500](#) > [TRB500 Manual](#) > [TRB500 WebUI](#) > [TRB500 Services section](#) > **TRB500 OPC UA Server**

The information in this page is updated in accordance with firmware version **TRB5\_R\_00.07.07.1**

**Note:** Firmware versions before **TRB5\_R\_00.07.04.4** will not be supported by devices from batch 09 and higher..



## Contents

- [1 Summary](#)
- [2 OPC UA Server Configuration](#)
- [3 OPC UA Server variables](#)

## Summary

OPC Unified Architecture (**OPC UA**) is a cross-platform, open-source, IEC62541 standard for data exchange from sensors to cloud applications developed by the OPC Foundation. The *UA* in OPC UA stands for “Unified Architecture” and refers to the latest specification of the standard. It differs from its predecessor in that it is platform-independent, moving away from COM/DCOM to purely binary TCP/IP or alternatively SOAP.

---

This manual page provides an overview of the OPC UA Server in TRB500 devices.

**Note:** OPC UA Server is additional software that can be installed from the [System → Package Manager](#) page.

## OPC UA Server Configuration

The **OPC UA Server Configuration** section is used to enable the local OPC UA server.



Field	Value	Description
Enable off   on; default: <b>off</b>		Enables OPC UA server.
Port integer [1..65535]; default: <b>none</b>		Service port.

# OPC UA Server variables

All **RUTOS** device variables are described in the table below:

**Note:** All the variables have these qualities in common:

- Namespace index is 1
- Node ID type is string
- Read-only
- Updated upon request

ID	Type	Description
sys_uptime	UINT32	System uptime in seconds.
sys_serial	String	Device serial number.
sys_devname	String	Device name.
sys_devcode	String	Device code.
sys_version	String	Firmware version.
sys_hostname	String	Hostname.
lan_mac	String	LAN MAC address.
lan_ip	String	IP address of LAN interface.
lan_mask	String	Subnet mask of LAN interface.
lan_gateway	String	Gateway IP address of LAN interface.
lan_dns	Array of String	IP addresses of LAN interface DNS servers.
wan_ip	Array of String	IP address of WAN interface.
io_dio_dir	Array of BOOL	Directions of digital input/output pins. 0=IN, 1=OUT.
io_dio	Array of BOOL	Values of digital input/output pins.
mob_modem_count	UINT32	Modem count.
mob_modem_imei	Array of String	Modem IMEI.
mob_modem_serial	Array of String	Modem serial number.
mob_modem_mnf	Array of String	Modem manufacturer name.
mob_modem_model	Array of String	Modem model name.
mob_modem_fw	Array of String	Modem firmware version string.
mob_modem_temp	Array of FLOAT	Modem temperature.
mob_sim_count	Array of UINT32	SIM count.

mob_sim	Array of UINT32	Selected SIM.
mob_sim_state	Array of String	SIM state.
mob_sim_iccid	Array of String	SIM ICCID.
mob_rssi	Array of INT32	RSSI.
mob_conn_type	Array of String	Data carrier type.
mob_conn_state	Array of String	Connection state.
mob_net_state	Array of String	Network link state.
mob_operator	Array of String	Operator name.