TRB500 Product Labels

 $\underline{\text{Main Page}} > \underline{\text{TRB Gateways}} > \underline{\text{TRB500}} > \underline{\text{TRB500 Manual}} > \mathbf{TRB500 \ Product \ Labels}$

The information in this page is relevant from ${\bf 001}$ batch.

Label/Print on the box



Information displayed after scanning QR code: SN:999999999;I:9999999999999;M:AABBCCDDEEFF;B:999; ▼		Information displayed after scanning SN Barcode: 999; 9999999999 ▼	Information displayed after scanning Barcode: 4779051840236
Text on the label/print	QR or Barcode equivalent	Descri	ption
TRB500000000*	-	Product code a.k.a., ordering code, displays under which product codes indicate different versions of the overall product smay support different LTE bands, come with different LTRB5000000000 is only for standard order codes	product. For example, devices with different product
SERIAL	SN	Serial number is a unique 10-digit device identifier. It is Remote Management System (RMS). The device can be $\hbox{\bf RMS}$ page	
IMEI	I	The IMEI (International Mobile Equipment Identity) is a cellular modules. GSM network operators use the IMEI $$	
LAN MAC	М	The media access control (MAC) address is a unique ide controller for communication in the data link layer (OSI Ethernet LAN MAC address - MAC address of the LAN Econnecting the device to Teltonika's Remote Management the System \rightarrow Administration \rightarrow RMS page	layer2) Ethernet network interface. It is also required when
EAN	-	The International Article Number (a.k.a. European Artic symbology and numbering system used in global trade to packaging configuration, from a specific manufacturer	
BATCH NO:	В	Batch number is a number that indicates the batch of \boldsymbol{m}	aterials

Label on the product



Information displayed after scanning QR code:		canning QR code:	Information displayed after scanning SN Barcode:	
	SN:99999999;I:9999999999;M:AABBCCDDEEFF;U:admin;PW:999999999;B:999; 999999999			
×			x	
	Text on the sticker	QR or Barcode equivalent	Description	
	SERIAL	SN	Serial number is a unique 10-digit device identifier. It is required when connecting the device to Teltonika's Remote Management System (RMS). The device can be added to RMS via the $\mathbf{System} \to \mathbf{Administration} \to \mathbf{RMS}$ page	
	IMEI	I	The IMEI (International Mobile Equipment Identity) is a unique 15 decimal digit number used to identify cellular modules. GSM network operators use the IMEI to identify devices in their networks	
	LAN MAC	М	The media access control (MAC) address is a unique identifier used to distinguish a network interface controller for communication in the data link layer (OSI layer2) Ethernet LAN MAC address - MAC address of the LAN Ethernet network interface. It is also required when connecting the device to Teltonika's Remote Management System (RMS). The device can be added to RMS via the $\mathbf{System} \rightarrow \mathbf{Administration} \rightarrow \mathbf{RMS}$ page	
	USERNAME	U	A default value "admin" is used for product connection	
	PASSWORD	PW	A custom passphrase used for product connection (at least 8 characters long)	
	BATCH NO:	В	Batch number is a number that indicates the batch of materials	