

RUT140 OPC UA Server

[Main Page](#) > [RUT Routers](#) > [RUT140](#) > [RUT140 Manual](#) > [RUT140 WebUI](#) > [RUT140 Services section](#) > **RUT140 OPC UA Server**

The information in this page is updated in accordance with firmware version [RUT14X_R_00.07.07.1](#).



Contents

- [1 Summary](#)
- [2 OPC UA Server Configuration](#)
- [3 OPC UA Server variables](#)

Summary

OPC Unified Architecture (**OPC UA**) is a cross-platform, open-source, IEC62541 standard for data exchange from sensors to cloud applications developed by the OPC Foundation. The *UA* in OPC UA stands for “Unified Architecture” and refers to the latest specification of the standard. It differs from its predecessor in that it is platform-independent, moving away from COM/DCOM to purely binary TCP/IP or alternatively SOAP.

This manual page provides an overview of the OPC UA Server in RUT140 devices.

Note: OPC UA Server is additional software that can be installed from the [System → Package Manager](#) page.

OPC UA Server Configuration

The **OPC UA Server Configuration** section is used to enable the local OPC UA server.



Field	Value	Description
Enable off on; default: off		Enables OPC UA server.
Port integer [1..65535]; default: none		Service port.

OPC UA Server variables

All **RUTOS** device variables are described in the table below:

Note: All the variables have these qualities in common:

- Namespace index is 1
- Node ID type is string
- Read-only
- Updated upon request

ID	Type	Description
sys_uptime	UINT32	System uptime in seconds.
sys_serial	String	Device serial number.
sys_devname	String	Device name.
sys_devcode	String	Device code.
sys_version	String	Firmware version.
sys_hostname	String	Hostname.
lan_mac	String	LAN MAC address.
lan_ip	String	IP address of LAN interface.
lan_mask	String	Subnet mask of LAN interface.
lan_gateway	String	Gateway IP address of LAN interface.
lan_dns	Array of String	IP addresses of LAN interface DNS servers.
wan_ip	Array of String	IP address of WAN interface.