

# RUTM08 Events Reporting

[Main Page](#) > [RUTM Routers](#) > [RUTM08](#) > [RUTM08 Manual](#) > [RUTM08 WebUI](#) > [RUTM08 Services section](#) > **RUTM08 Events Reporting**

The information in this page is updated in accordance with firmware version [RUTM\\_R\\_00.07.07.3](#).

□

## Contents

- [1 Summary](#)
- [2 Events Reporting Rules](#)
- [3 Events Reporting Configuration](#)
  - [3.1 Send email](#)

## Summary

The **Events Reporting** feature provides the possibility to configure rules that inform via email when certain trigger events occur.

This page is an overview of the Events Reporting section for RUTM08 devices.

## Events Reporting Rules

The **Events Reporting Rules** section is used to manage existing Events Reporting rules and to add new ones. Events Reporting Rules trigger on certain, user specified events and send an email to a specified number informing of the occurred event.

All possible trigger events are listed in the table below.

Event	Event subtype
<b>Config change</b>	Informs on changes to the device's configuration. Possible triggers are: <ul style="list-style-type: none"><li>• <i>Any config change</i></li><li>• <i>Specific config change</i></li></ul>
<b>New DHCP client</b>	Informs on new DHCP lease give outs. Possible triggers are: <ul style="list-style-type: none"><li>• <i>Connected from LAN</i></li></ul>

Informs on Ethernet port state (plugged in or unplugged) or speed (100 Mbps or 1000 Mbps) changes. Possible triggers are:

### **Ports state**

- *Link speed*
- *Link state*
- *Unplugged*
- *Plugged in*
- *LAN1*
- *LAN2*
- *LAN3*
- *LAN4*
- *WAN*

Informs after device reboot occurrences. Possible triggers are:

### **Reboot**

- *From button*
- *From Input/Output*
- *From Ping Reboot*
- *From wget Reboot*
- *From Reboot Scheduler*
- *From WebUI*
- *From SMS*
- *All*

Informs when device startup completed. Possible triggers are:

### **Startup**

- *Device startup completed*
- *After unexpected shutdown*

Informs on successful or unsuccessful SSH login attempts.

### **SSH**

Possible triggers are:

- *Successful authentication*
- *Unsuccessful authentication*
- *All*

Informs on changes to the device's network topology. Possible triggers are:

### **Topology changes**

- *Topology changes*

Informs on WAN failover occurrences. Possible triggers are:

### **WAN failover**

- *Switched to failover*
- *Switched to main*
- *All*

Informs on successful or unsuccessful HTTP/HTTPS login attempts. Possible triggers are:

### **WebUI**

- *Successful authentication*
- *Unsuccessful authentication*
- *All*

## **Events Reporting Configuration**

The Events Reporting Rules list is empty by default. Before you can begin configuration you must add at least one new rule. This can be done by clicking the 'Add' button:



After adding a rule you should be redirected to its configuration page.

### **Send email**

---

When an Events Reporting rule is configured to **send emails**, the device (this RUTM08) will connect to an existing email account when a user specified trigger event occurs and send an email to another email address informing of the occurred event.

In order to send emails, the device requires access to an existing email account. You can configure email accounts in the **System → Administration → [Recipients](#)** page. Allowing access to less secure apps may be required for some email service providers.



<b>Field</b>	<b>Value</b>	<b>Description</b>
Enable	off   on; default: <b>on</b>	Turns the rule on or off.
Event type	Config change   Startup   New DHCP client   Reboot   SSH   WebUI   Ports state   Topology changes   WAN Failover; default: <b>Config change</b>	Event that will trigger the rule.
Event subtype	Varies	More specific event type that will trigger the rule.
Action	Send email; default: <b>Send email</b>	Selects the method of reporting on the specified event.
Subject	string; default: <b>none</b>	Subject of the sent email.
Message text on Event	string; default: <b>Router name - %rn; Event type - %et; Event text - %ex; Time stamp - %ts;</b>	Text to be included in the body of the report email.
Email account	email account; default: <b>none</b>	The account that will be used to send an email.
Recipient's email address	email address; default: <b>none</b>	Email address of the recipient.
Send test email	- (interactive button)	Sends an email based on the current configuration. This is used to test whether the configuration works as intended.