TRB145 Product Labels

 $\underline{\text{Main Page}} > \underline{\text{TRB Gateways}} > \underline{\text{TRB145}} > \underline{\text{TRB145 Manual}} > \mathbf{TRB145 \ Product \ Labels}$

The information in this page is relevant from ${\bf 038}$ batch.

Label/Print on the box



		Information displayed after scanning SN Barcode:	Information displayed after scanning Barcode:
		999999999	4779027312415
×		×	×
Text on the label/print	QR or Barcode equivalent	Desc	ription
TRB145003000*	-		ich product code the device was manufactured. Different l product. For example, devices with different product ferent accessories, different firmware, etc.
SERIAL	SN	Serial number is a unique 10-digit device identifier. It Remote Management System (<u>RMS</u>). The device can be <u>RMS</u> page	
IMEI	I	The IMEI (International Mobile Equipment Identity) is cellular modules. GSM network operators use the IME	
EAN	-	The International Article Number (a.k.a. European Art symbology and numbering system used in global trade packaging configuration, from a specific manufacture	
BATCH NO:	В	Batch number is a number that indicates the batch of	materials

Label on the product



information displayed after scanning QR code:			information displayed after scanning SN Barcode:
SN:99999999;I:9999999999999;U:admin;PW:99999999;B:999;		9999999;U:admin;PW:999999	99;B:999; 9999999999
x			×
	Text on the sticker	QR or Barcode equivalent	Description
	SERIAL	SN	Serial number is a unique 10-digit device identifier. It is required when connecting the device to Teltonika's Remote Management System (\underline{RMS}). The device can be added to RMS via the $\underline{System} \rightarrow \underline{Administration} \rightarrow \underline{RMS}$ page
	IMEI	I	The IMEI (International Mobile Equipment Identity) is a unique 15 decimal digit number used to identify cellular modules. GSM network operators use the IMEI to identify devices in their networks
	USERNAME	U	A default value "admin" is used for product connection
	PASSWORD	PW	A custom passphrase used for product connection (at least 8 characters long)
	BATCH NO:	R	Batch number is a number that indicates the batch of materials