

RUT301 OPC UA Server

[Main Page](#) > [RUT Routers](#) > [RUT301](#) > [RUT301 Manual](#) > [RUT301 WebUI](#) > [RUT301 Services section](#) > **RUT301 OPC UA Server**

The information in this page is updated in accordance with firmware version
[RUT301_R_00.07.07.1](#).



Contents

- [1 Summary](#)
- [2 OPC UA Server Configuration](#)
- [3 OPC UA Server variables](#)

Summary

OPC Unified Architecture (**OPC UA**) is a cross-platform, open-source, IEC62541 standard for data exchange from sensors to cloud applications developed by the OPC Foundation. The *UA* in OPC UA stands for “Unified Architecture” and refers to the latest specification of the standard. It differs from its predecessor in that it is platform-independent, moving away from COM/DCOM to purely binary TCP/IP or alternatively SOAP.

This manual page provides an overview of the OPC UA Server in RUT301 devices.

Note: OPC UA Server is additional software that can be installed from the [System → Package Manager](#) page.

OPC UA Server Configuration

The **OPC UA Server Configuration** section is used to enable the local OPC UA server.



| Field | Value | Description |
|---|-------|------------------------|
| Enable off on; default: off | | Enables OPC UA server. |
| Port integer [1..65535]; default: none | | Service port. |

OPC UA Server variables

All **RUTOS** device variables are described in the table below:

Note: All the variables have these qualities in common:

- Namespace index is 1
- Node ID type is string
- Read-only
- Updated upon request

| ID | Type | Description |
|--------------|-----------------|---|
| sys_uptime | UINT32 | System uptime in seconds. |
| sys_serial | String | Device serial number. |
| sys_devname | String | Device name. |
| sys_devcode | String | Device code. |
| sys_version | String | Firmware version. |
| sys_hostname | String | Hostname. |
| lan_mac | String | LAN MAC address. |
| lan_ip | String | IP address of LAN interface. |
| lan_mask | String | Subnet mask of LAN interface. |
| lan_gateway | String | Gateway IP address of LAN interface. |
| lan_dns | Array of String | IP addresses of LAN interface DNS servers. |
| wan_ip | Array of String | IP address of WAN interface. |
| io_dio_dir | Array of BOOL | Directions of digital input/output pins. 0=IN, 1=OUT. |
| io_dio | Array of BOOL | Values of digital input/output pins. |