

# RUT900 Remote Monitoring & Administration

[Main Page](#) > [RUT Routers](#) > [RUT900](#) > [RUT900 Manual](#) > **RUT900 Remote Monitoring & Administration**

RUT900 supports multiple monitoring and administration possibilities.

□

## Contents

- [1 Remote control options](#)
  - [1.1 RMS](#)
  - [1.2 Public IP](#)
    - [1.2.1 HTTP access](#)
    - [1.2.2 SSH access](#)
  - [1.3 SMS](#)
  - [1.4 JSON-RPC](#)
  - [1.5 VPN](#)
  - [1.6 SNMP](#)
  - [1.7 Modbus TCP](#)
  - [1.8 MQTT](#)
  - [1.9 TR-069](#)

## Remote control options

The RUT900 router supports the following remote control capabilities:

| Remote control method  | Can get parameters                  | Can set parameters                  |
|------------------------|-------------------------------------|-------------------------------------|
| <a href="#">RMS</a>    | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">SSH</a>    | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">HTTP</a>   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">SMS</a>    | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">JSON</a>   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">VPN</a>    | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">SNMP</a>   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">Modbus</a> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">MQTT</a>   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| <a href="#">TR-069</a> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |

## RMS

---

The **Remote Management System (RMS)** is designed to conveniently monitor and manage all your Teltonika networking devices. The system allows to securely gather status information of your devices and to change their configuration even if the devices do not have public IP addresses.

RMS access can be configured from the **System** → **Administration** → [RMS](#) page.

## Public IP

---

If you're using a SIM card that has a Public IP address (refer [here](#) for more information), you can reach the router via HTTP or SSH via its WAN IP address.

### HTTP access

---

Remote **HTTP** access can be set up via the **System** → **Administration** → [Access Control](#) page.

### SSH access

---

Remote **SSH** access can be set up via the **System** → **Administration** → [Access Control](#) page.

## SMS

---

The router can be controlled via **SMS messages** using SMS utilities rules. SMS can be configured via the **Services** → **SMS Utilities** → [SMS Rules](#) page.

## JSON-RPC

---

**JSON-RPC** access can be set up via the **System** → **Administration** → [Access Control](#) page.

## VPN

---

**Virtual Private Networks (VPNs)** provide multiple flexible options on setting up remote access to the router and its LAN network. For more information on different types of VPNs supported by RUT900, visit the [VPN manual page](#).

## SNMP

---

**Simple Network Management Protocol (SNMP)** is a protocol for network management, used for collecting information from network devices. For more information on SNMP in RUT900, visit the [SNMP manual page](#).

## Modbus TCP

---

**Modbus** is a serial communications protocol used in communication with various types of industrial electronic devices. For more information on Modbus TCP in RUT900, visit the [Modbus manual page](#).

## MQTT

---

**MQTT (MQ Telemetry Transport or Message Queue Telemetry Transport)** is a publish-subscribe-based "lightweight" messaging protocol for use on top of the TCP/IP protocol. For more information on MQTT in RUT900, visit the [MQTT manual page](#)

## TR-069

---

**Technical Report 069 (TR-069)** is a technical specification of the Broadband Forum that defines an application layer protocol for remote management of customer-premises equipment (CPE) connected to an Internet Protocol (IP) network. For more information on TR-069 in RUT900, visit the [TR-069 manual page](#)